

Pre-Pickup inspection (polarity)


Lower discarded-part counts and cut equipment downtime to increase productivity!

Problems

■ Tray replacement: Tray set in the wrong direction




■ Parts relocation: Parts placed in the wrong direction



Misplacement caused by operator error in part orientation

Effects after license introduction

■ Pre-Pickup Inspection (Polarity) with head camera prevents misplacement



Automatic pickup angle correction function: Automatically corrects the angle for part pickup and placement.

Pre-Pickup Inspection (Polarity)

Lower discarded-part counts and cut equipment downtime to increase productivity!

■Precautions for use

1. This function requires a license and setup of a dedicated server.
2. There are restrictions such as inspectable polarity marks.
3. For further details and precautions, please refer to the instruction manual and the specification sheet.

■Applicable models

NPM Series
NPM-X Series
NPM-G Series
AM Series

■Restrictions

NPM Series: V10.09.06 or later
NPM-X Series: V 02.08.07 E or later
NPM-G Series: ALL
AM Series: V03.19.03 or later

*Contact us for details.