

Control Commands

Model No. PT-MZ882
PT-MZ782
PT-MZ682
PT-SMZ85C
PT-SMZ75C
PT-SMZ60CL
PT-SMZ58CAL



- Please refer to the Operating Instructions for the serial command format, limitations, connection and other details.
- シリアルコマンドのフォーマット、制限事項、接続方法およびその他詳細につきましては、各モデルの取扱説明書をご覧ください。
- 有关串行控制命令的格式、限制事项、连接方法以及其他详情、请参阅各机型的使用说明书。

Panasonic

| CATEGORY | FUNCTION | Parameter/Name | Sub-Parameter | CONTROL | | QUERY | | MZ882 SERIES MZ782 MZ682 SMZ85C SMZ75C SMZ60C SMZ58CA |
|-----------------------------------|-----------------------------|----------------|----------------------|--------------------|-------------------|-----------|---|---|
| | | | | COMMANDS/CALL BACK | COMMANDS | CALL BACK | | |
| BASIC OPERATION REMOTE CONTROL | POWER | ON | | PON | QPW | 001 | ✓ | |
| | | OFF (STANDBY) | | POF | | 000 | ✓ | |
| | VOLUME | UP | | AUU | | | ✓ | |
| | | DOWN | | AUD | | | ✓ | |
| | INPUT SELECT | COMPUTER1 | | IIS:RG1 | QIN | RG1 | ✓ | |
| | | COMPUTER2 | | IIS:RG2 | | RG2 | ✓ | |
| | | HDMI1 | | IIS:HD1 | | HD1 | ✓ | |
| | | HDMI2 | | IIS:HD2 | | HD2 | ✓ | |
| | | HDMI3 | | IIS:HD3 | | HD3 | ✓ | |
| | | DIGITAL LINK | | IIS:DL1 | | DL1 | ✓ | |
| | INPUT SELECT (DIGITAL LINK) | COMPUTER1 | | IIS:DL1:PC1 | QIN | DL1:PC1 | ✓ | |
| | | HDMI1 | | IIS:DL1:HD1 | | DL1:HD1 | ✓ | |
| | | HDMI2 | | IIS:DL1:HD2 | | DL1:HD2 | ✓ | |
| | FREEZE | OFF | | OFZ:0 | QFZ | 0 | ✓ | |
| | | ON | | OFZ:1 | | 1 | ✓ | |
| | MENU KEY | | | OMN | | | ✓ | |
| | RETURN KEY | | | OBK | | | ✓ | |
| | ENTER KEY | | | OEN | | | ✓ | |
| | UP KEY | | | OCU | | | ✓ | |
| | DOWN KEY | | | OCD | | | ✓ | |
| | LEFT KEY | | | OCL | | | ✓ | |
| | RIGHT KEY | | | OCR | | | ✓ | |
| | DEFAULT KEY | | | OST | | | ✓ | |
| | AUTO SETUP KEY | | | OAS | | | ✓ | |
| | SHUTTER | OFF | | OSH:0 | QSH | 0 | ✓ | |
| | | ON | | OSH:1 | | 1 | ✓ | |
| | SHUTTER(Toggle) | OFF | | OSH | QSH | 0 | ✓ | |
| | | ON | | | | 1 | ✓ | |
| | DIGITAL ZOOM UP | | | DZU | | | ✓ | |
| | DIGITAL ZOOM DOWN | | | DZD | | | ✓ | |
| | FUNCTION KEY | | | FC1 | | | ✓ | |
| | SYSTEM SELCTOR KEY | | | OSL | | | ✓ | |
| | ASPECT KEY | | | VSI | | | ✓ | |
| | ECO | | | OEC | | | ✓ | |
| | NUMERIC KEY | 0 | | ONK:0 | | | ✓ | |
| | | 1 | | ONK:1 | | | ✓ | |
| | | 2 | | ONK:2 | | | ✓ | |
| | | 3 | | ONK:3 | | | ✓ | |
| | | 4 | | ONK:4 | | | ✓ | |
| | | 5 | | ONK:5 | | | ✓ | |
| | | 6 | | ONK:6 | | | ✓ | |
| | | 7 | | ONK:7 | | | ✓ | |
| | | 8 | | ONK:8 | | | ✓ | |
| | | 9 | | ONK:9 | | | ✓ | |
| | LENS HOME POSITION | EXECUTE | | VXX:LNSI1=+00001 | | | ✓ | |
| | LENS SHIFT-HORIZONTAL | SLOW+ | | VXX:LNSI2=+00000 | | | ✓ | |
| | | SLOW- | | VXX:LNSI2=+00001 | | | ✓ | |
| | | NORMAL+ | | VXX:LNSI2=+00100 | | | ✓ | |
| | | NORMAL- | | VXX:LNSI2=+00101 | | | ✓ | |
| | | FAST+ | | VXX:LNSI2=+00200 | | | ✓ | |
| | FAST- | | VXX:LNSI2=+00201 | | | ✓ | | |
| LENS SHIFT-VERTICAL | SLOW+ | | VXX:LNSI3=+00000 | | | ✓ | | |
| | SLOW- | | VXX:LNSI3=+00001 | | | ✓ | | |
| | NORMAL+ | | VXX:LNSI3=+00100 | | | ✓ | | |
| | NORMAL- | | VXX:LNSI3=+00101 | | | ✓ | | |
| | FAST+ | | VXX:LNSI3=+00200 | | | ✓ | | |
| | FAST- | | VXX:LNSI3=+00201 | | | ✓ | | |
| LENS FOCUS | SLOW+ | | VXX:LNSI4=+00000 | | | ✓ | | |
| | SLOW- | | VXX:LNSI4=+00001 | | | ✓ | | |
| | NORMAL+ | | VXX:LNSI4=+00100 | | | ✓ | | |
| | NORMAL- | | VXX:LNSI4=+00101 | | | ✓ | | |
| | FAST+ | | VXX:LNSI4=+00200 | | | ✓ | | |
| | FAST- | | VXX:LNSI4=+00201 | | | ✓ | | |
| LENS ZOOM | SLOW+ | | VXX:LNSI5=+00000 | | | ✓ | | |
| | SLOW- | | VXX:LNSI5=+00001 | | | ✓ | | |
| | NORMAL+ | | VXX:LNSI5=+00100 | | | ✓ | | |
| | NORMAL- | | VXX:LNSI5=+00101 | | | ✓ | | |
| | FAST+ | | VXX:LNSI5=+00200 | | | ✓ | | |
| | FAST- | | VXX:LNSI5=+00201 | | | ✓ | | |
| STATUS KEY | | | STS | | | ✓ | | |
| LENS FOCUS KEY | | | OLF | | | ✓ | | |
| LENS SHIFT KEY | | | OLH | | | ✓ | | |
| LENS ZOOM KEY | | | OLZ | | | ✓ | | |
| DIGITAL LINK KEY | | | DLK | | | ✓ | | |
| INPUT MENU KEY | | | IPT | | | ✓ | | |
| P-TIMER | | | PTM | | | ✓ | | |
| SCREEN ADJUSTMENT | | | OSA | | | ✓ | | |
| AUDIO MUTE | OFF | | AMT:0 | QMT | 0 | ✓ | | |
| | ON | | AMT:1 | | 1 | ✓ | | |
| SELF DIAGNOSIS | | | | QVX:ERRS1 | ERRS1=***** | ✓ | | |
| PICTURE MODE | DYNAMIC | | VPM:DYN | QPM | DYN | ✓ | | |
| | NATURAL | | VPM:NAT | | NAT | ✓ | | |
| | STANDARD | | VPM:STD | | STD | ✓ | | |
| | WHITE BOARD | | VPM:WBD | | WBD | ✓ | | |
| | CINEMA | | VPM:CIN | | CIN | ✓ | | |
| | DICOM SIM. | | VPM:DIC | | DIC | ✓ | | |
| | MULTI-PROJECTION | | VPM:MLT | | MLT | ✓ | | |
| CONTRAST | +1 | | VCN:001 | QVR | 001 | ✓ | | |
| | +63 | | VCN:063 | | 063 | ✓ | | |
| BRIGHTNESS | +1 | | VBR:001 | QVB | 001 | ✓ | | |
| | +63 | | VBR:063 | | 063 | ✓ | | |
| COLOR | +1 | | VCO:001 | QVC | 001 | ✓ | | |
| | +63 | | VCO:063 | | 063 | ✓ | | |
| TINT | +1 | | VTN:001 | QVT | 001 | ✓ | | |
| | +63 | | VTN:063 | | 063 | ✓ | | |
| SHARPNESS | 0 | | VSR:000 | QVS | 000 | ✓ | | |
| | 15 | | VSR:015 | | 015 | ✓ | | |
| COLOR TEMPERATURE | LOW | | OTE:0 | QTE | 0 | ✓ | | |
| | HIGH | | OTE:2 | | 2 | ✓ | | |
| | USER | | OTE:4 | | 4 | ✓ | | |
| | USER1(USER) | | OTE:04 | | 4 | ✓ | | |
| | DEFAULT | | OTE:10 | | 10 | ✓ | | |
| COLOR TEMP-NAME SETTING USER1 | COLORTEMP1 | | VXX:NCGS1=COLORTEMP1 | QVX:NCGS1 | NCGS1=COLORTEMP1 | ✓ | | |
| COLOR TEMP-NAME SETTING USER2 | COLORTEMP2 | | VXX:NCGS3=COLORTEMP2 | QVX:NCGS3 | NCGS3=COLORTEMP2 | ✓ | | |
| COLOR TEMP-NAME CLEAR USER1 | COLORTEMP1 | | VXX:NCLI1=+00000 | | | ✓ | | |
| COLOR TEMP-NAME CLEAR USER2 | COLORTEMP2 | | VXX:NCLI3=+00000 | | | ✓ | | |
| WHITE BALANCE LOW-RED | -127 | | VOR:001 | QOR | 001 | ✓ | | |
| | +127 | | VOR:255 | | 255 | ✓ | | |
| WHITE BALANCE LOW-GREEN | -127 | | VOG:001 | QOG | 001 | ✓ | | |
| | +127 | | VOG:255 | | 255 | ✓ | | |
| WHITE BALANCE LOW-BLUE | -127 | | VOB:001 | QOB | 001 | ✓ | | |
| | +127 | | VOB:255 | | 255 | ✓ | | |
| WHITE BALANCE HIGH-RED | 0 | | VHR:000 | QHR | 000 | ✓ | | |
| | +255 | | VHR:255 | | 255 | ✓ | | |

| CATEGORY | FUNCTION | Parameter/Name | Sub-Parameter | CONTROL | | QUERY | | MZ882 SERIES |
|--|-----------------------------------|-------------------|--------------------------------------|--------------------------------------|------------------------------|------------------------------|----------------------------------|--|
| | | | | COMMANDS/CALL BACK | COMMANDS | CALL BACK | | |
| PICTURE | WHITE BALANCE HIGH-GREEN | 0 +255 | | VHG:000 VHG:255 | QHG | 000 255 | | MZ882 MZ782 MZ682 SMZ85C SMZ75C SMZ60C SMZ58CA |
| | WHITE BALANCE HIGH-BLUE | 0 +255 | | VHB:000 VHB:255 | QHB | 000 255 | | |
| | GAMMA(PRESET) | -8 +7 | | VXX:GAMI1=-00008 VXX:GAMI1=+00007 | QVX:GAMI1 | GAMI1=-00008 GAMI1=+00007 | | |
| | DAYLIGHT VIEW | OFF | | VXX:DLVI0=+00000 | QVX:DLVI0 | DLVI0=+00000 | | |
| | | AUTO | | VXX:DLVI0=+00001 | | DLVI0=+00001 | | |
| | | 1 | | VXX:DLVI0=+00002 | | DLVI0=+00002 | | |
| | | 2 | | VXX:DLVI0=+00003 | | DLVI0=+00003 | | |
| | NOISE REDUCTION | 3 | | VXX:DLVI0=+00004 | | DLVI0=+00004 | | |
| | | OFF | | VNS:0 | QNS | 0 | | |
| | | 1 | | VNS:1 | | 1 | | |
| | | 2 | | VNS:2 | | 2 | | |
| | DYNAMIC CONTRAST/IRIS | 3 | | VNS:3 | | 3 | | |
| | | OFF | | OAI:0 | QAI | 0 | | |
| | | 1 | | OAI:1 | | 1 | | |
| | | 2 | | OAI:2 | | 2 | | |
| DYNAMIC CONTRAST (LIGHTS OUT TIMER) | USER | | OAI:4 | | 4 | | | |
| | DISABLE | | VXX:DYCS2=OFF | QVX:DYCS2 | OFF | | | |
| | 0.0s | | VXX:DYCS2=0.0 | | 0.0 | | | |
| DYNAMIC CONTRAST (LIGHTS OUT SIGNAL LEVEL) | 10.0s | | VXX:DYCS2=10.0 | | 10.0 | | | |
| | 0 | | VXX:DYCI3=+00000 | QVX:DYCI3 | 00000 | | | |
| TV-SYSTEM | 5 | | VXX:DYCI3=+00005 | | 00005 | | | |
| | AUTO1 | | VSG:AT1 | QSG | AT1 | | | |
| | AUTO2 | | VSG:AT2 | | AT2 | | | |
| | NTSC | | VSG:NTS | | NTS | | | |
| | NTSC4.43 | | VSG:N44 | | N44 | | | |
| | PAL | | VSG:PAL | | PAL | | | |
| | PAL-M | | VSG:PAM | | PAM | | | |
| | PAL-N | | VSG:PAN | | PAN | | | |
| | PAL60 | | VSG:P60 | | P60 | | | |
| | SECAM | | VSG:SEC | | SEC | | | |
| SYSTEM SELECTOR RGB(VGA/480P) | VGA60 | | ORF:0 | QRF | 0 | | | |
| | 480P(YCbCr) | | ORF:1 | | 1 | | | |
| | 480p(RGB) | | ORF:3 | | 3 | | | |
| SYSTEM SELECTOR RGB(Other)/DVI/SLOT-DVI | RGB | | ORF:0 | QRF | 0 | | | |
| | YPbPr | | ORF:1 | | 1 | | | |
| SYSTEM SELECTOR HDMI/DIGITAL LINK/DisplayPort/SLOT-HDMI/SLOT-DIGITAL LINK/ | RGB | | ORF:0 | QRF | 0 | | | |
| | YPbPr | | ORF:1 | | 1 | | | |
| | AUTO | | ORF:2 | | 2 | | | |
| POSITION | REAL TIME KEYSTONE | OFF ON | | OAK:0 OAK:1 | QAK | 0 1 | | |
| | KEYSTONE-LENS THROW RATIO | 0.9 | | VXX:GMKS0=0.9 | QVX:GMKS0 | GMKS0=00.9 | | |
| | | 1.4 | | VXX:GMKS0=1.4 | | GMKS0=01.4 | | |
| | | 2.3 | | VXX:GMKS0=2.3 | | GMKS0=02.3 | | |
| | CURVED CORRECTION-HORIZONTAL ARC. | -40 | | VXX:GMCI7=-00040 | QVX:GMCI7 | GMCI7=-00040 | | |
| | | +40 | | VXX:GMCI7=+00040 | | GMCI7=+00040 | | |
| | CURVED CORRECTION-VERTICAL ARC | -40 | | VXX:GMCI3=-00040 | QVX:GMCI3 | GMCI3=-00040 | | |
| | | +40 | | VXX:GMCI3=+00040 | | GMCI3=+00040 | | |
| | GEOMETRY | OFF | | VXX:GMMI0=+00000 | QVX:GMMI0 | GMMI0=+00000 | | |
| | | KEYSTONE | | VXX:GMMI0=+00001 | | GMMI0=+00001 | | |
| | | CURVED | | VXX:GMMI0=+00002 | | GMMI0=+00002 | | |
| | | PC-1 | | VXX:GMMI0=+00003 | | GMMI0=+00003 | | |
| | | PC-2 | | VXX:GMMI0=+00004 | | GMMI0=+00004 | | |
| | | PC-3 | | VXX:GMMI0=+00005 | | GMMI0=+00005 | | |
| | | CORNER-CORRECTION | | VXX:GMMI0=+00010 | | GMMI0=+00010 | | |
| GEOMETRY-KEYSTONE-LENS THROW RATIO | 0.7 | 0.1 step | VXX:GMKS0=+00.7 | QVX:GMKS0 | GMKS0=+00.7 | | +00.5 | |
| | 16.5 | | VXX:GMKS0=+16.5 | | GMKS0=+16.5 | | +10.5 | |
| GEOMETRY-KEYSTONE-VERTICAL BALANCE | -60 +60 | | VXX:GMKI4=-00060 VXX:GMKI4=+00060 | QVX:GMKI4 | GMKI4=-00060 GMKI4=+00060 | | | |
| GEOMETRY-KEYSTONE-HORIZONTAL BALANCE | -30 +30 | | VXX:GMKI7=-00030 VXX:GMKI7=+00030 | QVX:GMKI7 | GMKI7=-00030 GMKI7=+00030 | | | |
| | -40.0 (-45.0)* +40.0 (+45.0)* | 0.2 step | VXX:GMKS8=-40.0 VXX:GMKS8=+40.0 | QVX:GMKS8 | GMKS8=-40.0 GMKS8=+40.0 | | -25.0(0.5step) +25.0(0.5step) | |
| GEOMETRY-KEYSTONE-HORIZONTAL KEYSTONE | -15.0 (-40.0)* +15.0 (+40.0)* | 0.2 step | VXX:GMKS9=-15.0 VXX:GMKS9=+15.0 | QVX:GMKS9 | GMKS9=-15.0 GMKS9=+15.0 | | -30.0(0.5step) +30.0(0.5step) | |
| | 0.7 16.5 | 0.1 step | VXX:GMCS0=+00.7 VXX:GMCS0=+16.5 | QVX:GMCS0 | GMCS0=+00.7 GMCS0=+16.5 | | +00.5 +10.5 | |
| GEOMETRY-CURVED-VERTICAL ARC | -50 (-100)* +50 (+100)* | | VXX:GMCI3=-00050 VXX:GMCI3=+00050 | QVX:GMCI3 | GMCI3=-00050 GMCI3=+00050 | | | |
| | -50 (-100)* +50 (+100)* | | VXX:GMCI7=-00050 VXX:GMCI7=+00050 | QVX:GMCI7 | GMCI7=-00050 GMCI7=+00050 | | | |
| GEOMETRY-CURVED-VERTICAL BALANCE | -60 +60 | | VXX:GMCI2=-00060 VXX:GMCI2=+00060 | QVX:GMCI2 | GMCI2=-00060 GMCI2=+00060 | | | |
| | -30 +30 | | VXX:GMCI6=-00030 VXX:GMCI6=+00030 | QVX:GMCI6 | GMCI6=-00030 GMCI6=+00030 | | | |
| GEOMETRY-CURVED-VERTICAL KEYSTONE | -40.0 (-45.0)* +40.0 (+45.0)* | 0.2 step | VXX:GMCS8=-40.0 VXX:GMCS8=+40.0 | QVX:GMCS8 | GMCS8=-40.0 GMCS8=+40.0 | | -25.0(0.5step) +25.0(0.5step) | |
| | -15.0 (-40.0)* +15.0 (+40.0)* | 0.2 step | VXX:GMCS9=-15.0 VXX:GMCS9=+15.0 | QVX:GMCS9 | GMCS9=-15.0 GMCS9=+15.0 | | -30.0(0.5step) +30.0(0.5step) | |
| GEOMETRY-CURVED-MAINTAIN ASPECT RATIO | OFF ON | | VXX:GMCI3=+00000 VXX:GMCI3=+00001 | QVX:GMCI3 | GMCI3=+00000 GMCI3=+00001 | | | |
| | min. max. | | VXX:GMFIA=+00000 VXX:GMFIA=+00300 | QVX:GMFIA | GMFIA=+00000 GMFIA=+00300 | | 0 +300 | |
| GEOMETRY-CORNER CORRECTION-UPPER LEFT(V) | min. max. | | VXX:GMFI1=+00000 VXX:GMFI1=+00300 | QVX:GMFI1 | GMFI1=+00000 GMFI1=+00300 | | 0 +300 | |
| | min. max. | | VXX:GMFI2=+00000 VXX:GMFI2=+00300 | QVX:GMFI2 | GMFI2=+00000 GMFI2=+00300 | | 0 +300 | |
| GEOMETRY-CORNER CORRECTION-UPPER RIGHT(V) | min. max. | | VXX:GMFI3=-00300 VXX:GMFI3=+00000 | QVX:GMFI3 | GMFI3=-00300 GMFI3=+00000 | | -300 0 | |
| | min. max. | | VXX:GMFI4=-00300 VXX:GMFI4=+00000 | QVX:GMFI4 | GMFI4=-00300 GMFI4=+00000 | | -300 0 | |
| GEOMETRY-CORNER CORRECTION-LOWER LEFT(V) | min. max. | | VXX:GMFI5=-00127 VXX:GMFI5=+00127 | QVX:GMFI5 | GMFI5=-00127 GMFI5=+00127 | | -127 +127 | |
| | min. max. | | VXX:GMFI6=+00000 VXX:GMFI6=+00480 | QVX:GMFI6 | GMFI6=+00000 GMFI6=+00480 | | 0 +480 | |
| GEOMETRY-CORNER CORRECTION-LOWER RIGHT(V) | min. max. | | VXX:GMFI7=-00480 VXX:GMFI7=+00000 | QVX:GMFI7 | GMFI7=-00480 GMFI7=+00000 | | -480 0 | |
| | min. max. | | VXX:GMFI8=+00000 VXX:GMFI8=+00480 | QVX:GMFI8 | GMFI8=+00000 GMFI8=+00480 | | 0 +480 | |
| GEOMETRY-CORNER CORRECTION-LOWER RIGHT(H) | min. max. | | VXX:GMFI9=-00480 VXX:GMFI9=+00000 | QVX:GMFI9 | GMFI9=-00480 GMFI9=+00000 | | -480 0 | |
| | min. max. | | VXX:GMFIA=-00127 VXX:GMFIA=+00127 | QVX:GMFIA | GMFIA=-00127 GMFIA=+00127 | | -127 +127 | |
| GEOMETRY-CORNER CORRECTION-LINEARITY(H) | min. max. | | VXX:GMFIF=+00000 VXX:GMFIF=+00001 | QVX:GMFIF | GMFIF=+00000 GMFIF=+00001 | | 0 +1 | |
| | AUTO MANUAL | | VTH:0000 VTH:4095 | QTH | 0000 4095 | | 0 4095 | |
| SHIFT-HORIZONTAL | 0 +4095 | | VTV:0000 VTV:4094 | QTV | 0000 4094 | | 0 4094 | |
| | 0 +4094 | | VCP:000 VCP:031 | QCP | 000 063 | | 0 063 | |
| CLOCK PHASE | 0 +31 | | VSE:0 VSE:1 | QSE | 0 1 | | 0 1 | |
| | 0 +31 | | VSE:2 | | 2 | | 2 | |
| ASPECT | AUTO/VID AUTO/DEFAULT | | VSE:0 VSE:1 | | 0 1 | | 0 1 | |
| | NORMAL(4:3) WIDE(16:9) | | VSE:2 | | 2 | | 2 | |

| CATEGORY | FUNCTION | Parameter/Name | Sub-Parameter | CONTROL | | QUERY | | MZ882 SERIES |
|----------|--|------------------------------|---------------|--|------------|--|--|---------------|
| | | | | COMMANDS/CALL BACK | COMMANDS | CALL BACK | | |
| | | NATIVE(through) | | VSE: 5 | | 5 | | ✓ |
| | | FULL(HV FIT) | | VSE: 6 | | 6 | | ✓ |
| | | H-FIT | | VSE: 9 | | 9 | | ✓ |
| | | V-FIT | | VSE: 10 | | 10 | | ✓ |
| | ZOOM-HORIZONTAL | 50 999 | | OZH:050 OZH:999 | QZH | 050 999 | | ✓ ✓ |
| | ZOOM-VERTICAL | 50 999 | | OZV:050 OZV:999 | QZV | 050 999 | | ✓ ✓ |
| | ZOOM-BOTH | 50 999 | | OZO:050 OZO:999 | QZO | 050 999 | | ✓ ✓ |
| | ZOOM-INTERLOCKED | OFF ON | | OZS:0 OZS:1 | QZS | 0 1 | | ✓ ✓ |
| | ZOOM-MODE | INTERNAL FULL | | OZT:0 OZT:1 | QZT | 0 1 | | ✓ ✓ |
| | FRAME LOCK | OFF ON | | VFL:0 VFL:1 | QFL | 0 1 | | ✓ ✓ |
| ADVANCED | DIGITAL CINEMA REALITY | AUTO OFF 30p/25p FIXED | | OPD:0 OPD:1 OPD:2 | QPD | 0 1 2 | | ✓ ✓ ✓ |
| | BLANKING-UPPER | min. max. | | DBU:0000 DBU:2398 | QLU | 0000 2398 | | 0 599 |
| | BLANKING-LOWER | min. max. | | DBB:0000 DBB:2398 | QLB | 0000 2398 | | 0 599 |
| | BLANKING-RIGHT | min. max. | | DBR:0000 DBR:3838 | QLR | 0000 3838 | | 0 959 |
| | BLANKING-LEFT | min. max. | | DBL:0000 DBL:3838 | QLL | 0000 3838 | | 0 959 |
| | INPUT RESOLUTION-TOTAL DOTS | 330 4095 | | VTD:0330 VTD:4095 | QTD | 0330 4095 | | ✓ ✓ |
| | INPUT RESOLUTION-DISPLAY DOTS | 300 4065 | | VDD:0300 VDD:4065 | QDD | 0300 4065 | | ✓ ✓ |
| | INPUT RESOLUTION-TOTAL LINES | 155 2047 | | VTL:0155 VTL:2047 | QTL | 0155 2047 | | ✓ ✓ |
| | INPUT RESOLUTION-DISPLAY LINES | 150 2037 | | VDL:0150 VDL:2037 | QDL | 0150 2037 | | ✓ ✓ |
| | CLAMP POSITION | 1 255 | | VLT:001 VLT:255 | QLT | 001 255 | | ✓ ✓ |
| | EDGE BLENDING | OFF ON | | VXX:EDBI0=+00000 VXX:EDBI0=+00001 | QVX:EDBI0 | EDBI0=+00000 EDBI0=+00001 | | ✓ ✓ |
| | EDGE BLENDING-UPPER ON/OFF | OFF ON | | VGU:0 VGU:1 | QGU | 0 1 | | ✓ ✓ |
| | EDGE BLENDING-LOWER ON/OFF | OFF ON | | VGB:0 VGB:1 | QGB | 0 1 | | ✓ ✓ |
| | EDGE BLENDING-LEFT ON/OFF | OFF ON | | VGL:0 VGL:1 | QGL | 0 1 | | ✓ ✓ |
| | EDGE BLENDING-RIGHT ON/OFF | OFF ON | | VGR:0 VGR:1 | QGR | 0 1 | | ✓ ✓ |
| | EDGE BLENDING-START-UPPER | min. max. | | VEU:0000 VEU:2272 | QEU | 0000 2272 | | ✓ 1200 |
| | EDGE BLENDING-START-LOWER | min. max. | | VEB:0000 VEB:2272 | QEB | 0000 2272 | | ✓ 1200 |
| | EDGE BLENDING-START-LEFT | min. max. | | VEL:0000 VEL:3712 | QEL | 0000 3712 | | ✓ 1920 |
| | EDGE BLENDING-START-RIGHT | min. max. | | VER:0000 VER:3712 | QER | 0000 3712 | | ✓ 1920 |
| | EDGE BLENDING-WIDTH-UPPER | min. max. | | VXX:EUWIO=+00000 VXX:EUWIO=+02272 | QVX:EUWIO | EUWIO=+00000 EUWIO=+02272 | | ✓ 1200 |
| | EDGE BLENDING-WIDTH-LOWER | min. max. | | VXX:EBWIO=+00000 VXX:EBWIO=+02272 | QVX:EBWIO | EBWIO=+00000 EBWIO=+02272 | | ✓ 1200 |
| | EDGE BLENDING-WIDTH-LEFT | min. max. | | VXX:ELWIO=+00000 VXX:ELWIO=+03712 | QVX:ELWIO | ELWIO=+00000 ELWIO=+03712 | | ✓ 1920 |
| | EDGE BLENDING-WIDTH-RIGHT | min. max. | | VXX:ERWIO=+00000 VXX:ERWIO=+03712 | QVX:ERWIO | ERWIO=+00000 ERWIO=+03712 | | ✓ 1920 |
| | EDGE BLENDING-MARKER-ON/OFF | OFF ON | | VGM:0 VGM:1 | QGM | 0 1 | | ✓ ✓ |
| | EDGE BLENDING-NON-OVERLAPPED BLACK LEVEL | 0 (W,R,G,B) 255 (W,R,G,B) | | VJI:000,000,000,000 VJI:255,255,255,255 | QJI | 000,000,000,000 255,255,255,255 | | ✓ ✓ |
| | EDGE BLENDING-NON-OVERLAPPED BLACK LEVEL-INTERLOCKED | OFF ON | | VXX:EBII1=+00000 VXX:EBII1=+00001 | QVX:EBII1 | EBII1=+00000 EBII1=+00001 | | ✓ ✓ |
| | EDGE BLENDING-BLACK BORDER LEVEL | 0 (W,R,G,B) 255 (W,R,G,B) | | VJO:000,000,000,000 VJO:255,255,255,255 | QJO | 000,000,000,000 255,255,255,255 | | ✓ ✓ |
| | EDGE BLENDING-BLACK BORDER LEVEL-INTERLOCKED | OFF ON | | VXX:EBII2=+00000 VXX:EBII2=+00001 | QVX:EBII2 | EBII2=+00000 EBII2=+00001 | | ✓ ✓ |
| | EDGE BLENDING-BLACK BORDER WIDTH-UPPER | min. max. | | VJU:0000 VJU:2272 | QJU | 0000 2272 | | ✓ 1200 |
| | EDGE BLENDING-BLACK BORDER WIDTH-LOWER | min. max. | | VJB:0000 VJB:2272 | QJB | 0000 2272 | | ✓ 1200 |
| | EDGE BLENDING-BLACK BORDER WIDTH-LEFT | min. max. | | VJL:0000 VJL:3712 | QJL | 0000 3712 | | ✓ 1920 |
| | EDGE BLENDING-BLACK BORDER WIDTH-RIGHT | min. max. | | VJR:0000 VJR:3712 | QJR | 0000 3712 | | ✓ 1920 |
| | EDGE BLENDING-BLACK BORDER WIDTH-UPPER KEYSTONE AREA | min. max. | | VXX:EBBI4=-02272 VXX:EBBI4=+02272 | QVX:EBBI4 | EBBI4=-02272 EBBI4=+02272 | | -1200 1200 |
| | EDGE BLENDING-BLACK BORDER WIDTH-LOWER KEYSTONE AREA | min. max. | | VXX:EBBI5=-02272 VXX:EBBI5=+02272 | QVX:EBBI5 | EBBI5=-02272 EBBI5=+02272 | | -1200 1200 |
| | EDGE BLENDING-BLACK BORDER WIDTH-LEFT KEYSTONE AREA | min. max. | | VXX:EBBI6=-03712 VXX:EBBI6=+03712 | QVX:EBBI6 | EBBI6=-03712 EBBI6=+03712 | | -1920 1920 |
| | EDGE BLENDING-BLACK BORDER WIDTH-RIGHT KEYSTONE AREA | min. max. | | VXX:EBBI7=-03712 VXX:EBBI7=+03712 | QVX:EBBI7 | EBBI7=-03712 EBBI7=+03712 | | -1920 1920 |
| | EDGE BLENDING-OVERLAPPED BLACK LEVEL-UPPER | 0 (W,R,G,B) 255 (W,R,G,B) | | VXX:EBBS0=000,000,000,000 VXX:EBBS0=255,255,255,255 | QVX:EBBS0 | EBBS0=000,000,000,000 EBBS0=255,255,255,255 | | ✓ ✓ |
| | EDGE BLENDING-OVERLAPPED BLACK LEVEL-LOWER | 0 (W,R,G,B) 255 (W,R,G,B) | | VXX:EBBS1=000,000,000,000 VXX:EBBS1=255,255,255,255 | QVX:EBBS1 | EBBS1=000,000,000,000 EBBS1=255,255,255,255 | | ✓ ✓ |
| | EDGE BLENDING-OVERLAPPED BLACK LEVEL-LEFT | 0 (W,R,G,B) 255 (W,R,G,B) | | VXX:EBBS2=000,000,000,000 VXX:EBBS2=255,255,255,255 | QVX:EBBS2 | EBBS2=000,000,000,000 EBBS2=255,255,255,255 | | ✓ ✓ |
| | EDGE BLENDING-OVERLAPPED BLACK LEVEL-RIGHT | 0 (W,R,G,B) 255 (W,R,G,B) | | VXX:EBBS3=000,000,000,000 VXX:EBBS3=255,255,255,255 | QVX:EBBS3 | EBBS3=000,000,000,000 EBBS3=255,255,255,255 | | ✓ ✓ |
| | EDGE BLENDING-OVERLAPPED BLACK LEVEL-UPPER INTERLOCKED | OFF ON | | VXX:EBII3=+00000 VXX:EBII3=+00001 | QVX:EBII3 | EBII3=+00000 EBII3=+00001 | | ✓ ✓ |
| | EDGE BLENDING-OVERLAPPED BLACK LEVEL-LOWER INTERLOCKED | OFF ON | | VXX:EBII4=+00000 VXX:EBII4=+00001 | QVX:EBII4 | EBII4=+00000 EBII4=+00001 | | ✓ ✓ |
| | EDGE BLENDING-OVERLAPPED BLACK LEVEL-LEFT INTERLOCKED | OFF ON | | VXX:EBII5=+00000 VXX:EBII5=+00001 | QVX:EBII5 | EBII5=+00000 EBII5=+00001 | | ✓ ✓ |
| | EDGE BLENDING-OVERLAPPED BLACK LEVEL-RIGHT INTERLOCKED | OFF ON | | VXX:EBII6=+00000 VXX:EBII6=+00001 | QVX:EBII6 | EBII6=+00000 EBII6=+00001 | | ✓ ✓ |
| | EDGE BLENDING-AUTO TESTPATTERN | OFF ON | | VXX:EATII1=+00000 VXX:EATII1=+00001 | QVX:EATII1 | EATII1=+00000 EATII1=+00001 | | ✓ ✓ |
| | RASTER POSITION-HORIZONTAL | -2048 +2047 | | VRH:2952 VRH:7047 | QRH | 2952 7047 | | ✓ ✓ |
| | RASTER POSITION-VERTICAL | -2048 +2047 | | VRV:2952 VRV:7047 | QRV | 2952 7047 | | ✓ ✓ |
| | LANGUAGE | English German French | | OLG:ENG OLG:DEU OLG:FRA | QLG | ENG DEU FRA | | ✓ ✓ ✓ |

| CATEGORY | FUNCTION | Parameter/Name | Sub-Parameter | CONTROL | | QUERY | MZ882 SERIES |
|------------------|---|-----------------------|---------------|----------------------------|-----------|------------------------|--------------|
| | | | | COMMANDS/CALL BACK | COMMANDS | CALL BACK | |
| DISPLAY LANGUAGE | | Spanish | | OLG:ESP | | ESP | ✓ |
| | | Italian | | OLG:ITL | | ITL | ✓ |
| | | Japanese | | OLG:JPN | | JPN | ✓ |
| | | Chinese | | OLG:CHI | | CHI | ✓ |
| | | Russian | | OLG:RUS | | RUS | ✓ |
| | | Korea | | OLG:KOR | | KOR | ✓ |
| | | Portuguse | | OLG:POR | | POR | ✓ |
| | | Swedish | | OLG:SVE | | SVE | ✓ |
| | | Norwegian | | OLG:NOR | | NOR | ✓ |
| | | Danish | | OLG:DAN | | DAN | ✓ |
| | | Polish | | OLG:POL | | POL | ✓ |
| | | Czech | | OLG:CES | | CES | ✓ |
| | | Hungarian | | OLG:MAG | | MAG | ✓ |
| | | Thai | | OLG:THA | | THA | ✓ |
| | | Dutch | | OLG:NLD | | NLD | ✓ |
| | | Finnish | | OLG:FIN | | FIN | ✓ |
| | | Romanian | | OLG:RUM | | RUM | ✓ |
| | Turkish | | OLG:TUR | | TUR | ✓ | |
| | Arabic | | OLG:ARA | | ARA | ✓ | |
| | Kazakh | | OLG:KAZ | | KAZ | ✓ | |
| | Vietnamese | | OLG:VIE | | VIE | ✓ | |
| | COLOR MATCHING | OFF | | VXX:CMAI0=+00000 | QVX:CMAI0 | CMAI0=+00000 | ✓ |
| | | 3COLORS | | VXX:CMAI0=+00001 | | CMAI0=+00001 | ✓ |
| | | 7COLORS | | VXX:CMAI0=+00002 | | CMAI0=+00002 | ✓ |
| | COLOR MATCHING-3COLORS-RED | 0 (R,G,B) | | VMR:0000,0000,0000 | QMR | 0000,0000,0000 | ✓ |
| | | 2048,2048,2048(R,G,B) | | VMR:2048,2048,2048 | | 2048,2048,2048 | ✓ |
| | COLOR MATCHING-3COLORS-GREEN | 0 (R,G,B) | | VMG:0000,0000,0000 | QMG | 0000,0000,0000 | ✓ |
| | | 2048,2048,2048(R,G,B) | | VMG:2048,2048,2048 | | 2048,2048,2048 | ✓ |
| | COLOR MATCHING-3COLORS-BLUE | 0 (R,G,B) | | VMB:0000,0000,0000 | QMB | 0000,0000,0000 | ✓ |
| | | 2048,2048,2048(R,G,B) | | VMB:2048,2048,2048 | | 2048,2048,2048 | ✓ |
| | COLOR MATCHING-3COLORS-WHITE | 256 (GAIN) | | VMW:0256 | QMW | 0256 | ✓ |
| | | 2048(GAIN) | | VMW:2048 | | 2048 | ✓ |
| | COLOR MATCHING-3COLORS-AUTO TESTPATTERN | OFF | | VXX:CATI0=+00000 | QVX:CATI0 | CATI0=+00000 | ✓ |
| | | ON | | VXX:CATI0=+00001 | | CATI0=+00001 | ✓ |
| | COLOR MATCHING-7COLORS-RED | 0 (R,G,B) | | VXX:C7CS0=0000,0000,0000 | QVX:C7CS0 | C7CS0=0000,0000,0000 | ✓ |
| | | 2048(R,G,B) | | VXX:C7CS0=2048,2048,2048 | | C7CS0=2048,2048,2048 | ✓ |
| | COLOR MATCHING-7COLORS-GREEN | 0 (R,G,B) | | VXX:C7CS1=0000,0000,0000 | QVX:C7CS1 | C7CS1=0000,0000,0000 | ✓ |
| | | 2048(R,G,B) | | VXX:C7CS1=2048,2048,2048 | | C7CS1=2048,2048,2048 | ✓ |
| | COLOR MATCHING-7COLORS-BLUE | 0 (R,G,B) | | VXX:C7CS2=0000,0000,0000 | QVX:C7CS2 | C7CS2=0000,0000,0000 | ✓ |
| | | 2048(R,G,B) | | VXX:C7CS2=2048,2048,2048 | | C7CS2=2048,2048,2048 | ✓ |
| | COLOR MATCHING-7COLORS-CYAN | 0 (R,G,B) | | VXX:C7CS3=0000,0000,0000 | QVX:C7CS3 | C7CS3=0000,0000,0000 | ✓ |
| | | 2048(R,G,B) | | VXX:C7CS3=2048,2048,2048 | | C7CS3=2048,2048,2048 | ✓ |
| | COLOR MATCHING-7COLORS-MAGENTA | 0 (R,G,B) | | VXX:C7CS4=0000,0000,0000 | QVX:C7CS4 | C7CS4=0000,0000,0000 | ✓ |
| | | 2048(R,G,B) | | VXX:C7CS4=2048,2048,2048 | | C7CS4=2048,2048,2048 | ✓ |
| | COLOR MATCHING-7COLORS-YELLOW | 0 (R,G,B) | | VXX:C7CS5=0000,0000,0000 | QVX:C7CS5 | C7CS5=0000,0000,0000 | ✓ |
| | | 2048(R,G,B) | | VXX:C7CS5=2048,2048,2048 | | C7CS5=2048,2048,2048 | ✓ |
| | COLOR MATCHING-7COLORS-WHITE | 0 (R,G,B) | | VXX:C7CS6=0000,0000,0000 | QVX:C7CS6 | C7CS6=0000,0000,0000 | ✓ |
| | | 2048(R,G,B) | | VXX:C7CS6=2048,2048,2048 | | C7CS6=2048,2048,2048 | ✓ |
| | COLOR MATCHING-7COLORS-AUTO TESTPATTERN | OFF | | VXX:CATI1=+00000 | QVX:CATI1 | CATI1=+00000 | ✓ |
| | | ON | | VXX:CATI1=+00001 | | CATI1=+00001 | ✓ |
| | COLOR CORRECTION | OFF | | VCM:0 | QMC | 0 | ✓ |
| | | USER | | VCM:1 | | 1 | ✓ |
| | COLOR CORRECTION-RED | -30 | | VXX:CCRI0=-00030 | QVX:CCRI0 | CCRI0=-00030 | ✓ |
| | | +30 | | VXX:CCRI0=+00030 | | CCRI0=+00030 | ✓ |
| | COLOR CORRECTION-GREEN | -30 | | VXX:CCRI1=-00030 | QVX:CCRI1 | CCRI1=-00030 | ✓ |
| | | +30 | | VXX:CCRI1=+00030 | | CCRI1=+00030 | ✓ |
| | COLOR CORRECTION-BLUE | -30 | | VXX:CCRI2=-00030 | QVX:CCRI2 | CCRI2=-00030 | ✓ |
| | | +30 | | VXX:CCRI2=+00030 | | CCRI2=+00030 | ✓ |
| | COLOR CORRECTION-CYAN | -30 | | VXX:CCRI3=-00030 | QVX:CCRI3 | CCRI3=-00030 | ✓ |
| | | +30 | | VXX:CCRI3=+00030 | | CCRI3=+00030 | ✓ |
| | COLOR CORRECTION-MAGENTA | -30 | | VXX:CCRI4=-00030 | QVX:CCRI4 | CCRI4=-00030 | ✓ |
| | | +30 | | VXX:CCRI4=+00030 | | CCRI4=+00030 | ✓ |
| | COLOR CORRECTION-YELLOW | -30 | | VXX:CCRI5=-00030 | QVX:CCRI5 | CCRI5=-00030 | ✓ |
| | | +30 | | VXX:CCRI5=+00030 | | CCRI5=+00030 | ✓ |
| | AUTO SIGNAL | OFF | | VXX:AASIO=+00000 | QVX:AASIO | AASIO=+00000 | ✓ |
| | | ON | | VXX:AASIO=+00001 | | AASIO=+00001 | ✓ |
| | AUTO SETUP -MODE | USER | | OAM:0 | QAM | 0 | ✓ |
| | | DEFAULT | | OAM:1 | | 1 | ✓ |
| | | WIDE | | OAM:2 | | 2 | ✓ |
| | AUTO SETUP -POSITION ADJ. | OFF | | VXX:APAI0=+00000 | QVX:APAI0 | APAI0=+00000 | ✓ |
| | | ON | | VXX:APAI0=+00001 | | APAI0=+00001 | ✓ |
| | RGB IN-RGB1 SYNC SLICE LEVEL | LOW | | VXX:STRI0=+00000 | QVX:STRI0 | STRI0=+00000 | ✓ |
| | | HIGH | | VXX:STRI0=+00001 | | STRI0=+00001 | ✓ |
| | RGB IN-RGB1 EDID MODE | DEFAULT | | VXX:EDMI7=+00000 | QVX:EDMI7 | EDMI7=+00000 | ✓ |
| | | SCREEB FIT | | VXX:EDMI7=+00001 | | EDMI7=+00001 | ✓ |
| | | USER | | VXX:EDMI7=+00010 | | EDMI7=+00010 | ✓ |
| | RGB IN-RGB1 EDID RESOLUTION | 1024x768p | | VXX:EDRS7=1024:0768:p | QVX:EDRS7 | EDRS7=1024:0768:p | ✓ |
| | | 1280x720p | | VXX:EDRS7=1280:0720:p | | EDRS7=1280:0720:p | ✓ |
| | | 1280x800p | | VXX:EDRS7=1280:0800:p | | EDRS7=1280:0800:p | ✓ |
| | | 1280x1024p | | VXX:EDRS7=1280:1024:p | | EDRS7=1280:1024:p | ✓ |
| | | 1366x768p | | VXX:EDRS7=1366:0768:p | | EDRS7=1366:0768:p | ✓ |
| | | 1400x1050p | | VXX:EDRS7=1400:1050:p | | EDRS7=1400:1050:p | ✓ |
| | | 1440x900p | | VXX:EDRS7=1440:0900:p | | EDRS7=1440:0900:p | ✓ |
| | | 1600x900p | | VXX:EDRS7=1600:0900:p | | EDRS7=1600:0900:p | ✓ |
| | | 1600x1200p | | VXX:EDRS7=1600:1200:p | | EDRS7=1600:1200:p | ✓ |
| | | 1680x1050p | | VXX:EDRS7=1680:1050:p | | EDRS7=1680:1050:p | ✓ |
| | | 1920x1080p | | VXX:EDRS7=1920:1080:p | | EDRS7=1920:1080:p | ✓ |
| | | 1920x1080i | | VXX:EDRS7=1920:1080:i | | EDRS7=1920:1080:i | ✓ |
| | | 1920x1200p | | VXX:EDRS7=1920:1200:p | | EDRS7=1920:1200:p | ✓ |
| | RGB IN-RGB1 EDID VERTICAL SCAN FREQUENCY | 60Hz | | VXX:EDVI7=+06000 | QVX:EDVI7 | EDVI7=+06000 | ✓ |
| | | 50Hz | | VXX:EDVI7=+05000 | | EDVI7=+05000 | ✓ |
| | | 48Hz | | VXX:EDVI7=+04800 | | EDVI7=+04800 | ✓ |
| | | 30Hz | | VXX:EDVI7=+03000 | | EDVI7=+03000 | ✓ |
| | | 25Hz | | VXX:EDVI7=+02500 | | EDVI7=+02500 | ✓ |
| | | 24Hz | | VXX:EDVI7=+02400 | | EDVI7=+02400 | ✓ |
| | RGB IN-RGB1 EDID RESOLUTION / VERTICAL SCAN FREQUENCY | * PARAMETER | | VXX:EDGS1=*****:*:**** | QVX:EDGS1 | EDGS1=*****:*:**** | ✓ |
| | | * PARAMETER1 | 1024x768 | VXX:EDGS1=1024:0768:*:**** | | EDGS1=1024:0768:*:**** | ✓ |
| | | | 1280x720 | VXX:EDGS1=1280:0720:*:**** | | EDGS1=1280:0720:*:**** | ✓ |
| | | | 1280x800 | VXX:EDGS1=1280:0800:*:**** | | EDGS1=1280:0800:*:**** | ✓ |
| | | | 1280x1024 | VXX:EDGS1=1280:1024:*:**** | | EDGS1=1280:1024:*:**** | ✓ |
| | | | 1366x768 | VXX:EDGS1=1366:0768:*:**** | | EDGS1=1366:0768:*:**** | ✓ |
| | | | 1400x1050 | VXX:EDGS1=1400:1050:*:**** | | EDGS1=1400:1050:*:**** | ✓ |
| | | | 1440x900 | VXX:EDGS1=1440:0900:*:**** | | EDGS1=1440:0900:*:**** | ✓ |
| | | | 1600x900 | VXX:EDGS1=1600:0900:*:**** | | EDGS1=1600:0900:*:**** | ✓ |
| | | | 1600x1200 | VXX:EDGS1=1600:1200:*:**** | | EDGS1=1600:1200:*:**** | ✓ |
| | | | 1680x1050 | VXX:EDGS1=1680:1050:*:**** | | EDGS1=1680:1050:*:**** | ✓ |
| | | | 1920x1080 | VXX:EDGS1=1920:1080:*:**** | | EDGS1=1920:1080:*:**** | ✓ |
| | | | 1920x1200 | VXX:EDGS1=1920:1200:*:**** | | EDGS1=1920:1200:*:**** | ✓ |
| | | * PARAMETER2 | Progressive | VXX:EDGS1=*****:p:**** | | EDGS1=*****:p:**** | ✓ |
| | | | Interlace | VXX:EDGS1=*****:i:**** | | EDGS1=*****:i:**** | ✓ |
| | | * PARAMETER3 | 60Hz | VXX:EDGS1=*****:*:6000 | | EDGS1=*****:*:6000 | ✓ |
| | | | 50Hz | VXX:EDGS1=*****:*:5000 | | EDGS1=*****:*:5000 | ✓ |
| | | | 48Hz | VXX:EDGS1=*****:*:4800 | | EDGS1=*****:*:4800 | ✓ |
| | | | 30Hz | VXX:EDGS1=*****:*:3000 | | EDGS1=*****:*:3000 | ✓ |

| CATEGORY | FUNCTION | Parameter/Name | Sub-Parameter | CONTROL | QUERY | MZ882 SERIES | | | |
|--|---|---------------------|---------------|--|-----------------------|--|--|--------------------|---|
| | | | | COMMANDS/CALL BACK | COMMANDS | | CALL BACK | | |
| | | | 25Hz | VXX:EDGS1=*****:*:2500 | | EDGS1=*****:*:2500 | ✓ | | |
| | | | 24Hz | VXX:EDGS1=*****:*:2400 | | EDGS1=*****:*:2400 | ✓ | | |
| RGB IN-RGB1 EDID STATUS RESOLUTION / VERTICAL SCAN FREQUENCY | * PARAMETER | * PARAMETER1 | 1024x768 | | QVX:ESGS1 | ESGS1=*****:*:**** | ✓ | | |
| | | | 1280x720 | | | ESGS1=1024:0768:*:**** | ✓ | | |
| | | | 1280x800 | | | ESGS1=1280:0720:*:**** | ✓ | | |
| | | | 1280x1024 | | | ESGS1=1280:0800:*:**** | ✓ | | |
| | | | 1366x768 | | | ESGS1=1280:1024:*:**** | ✓ | | |
| | | | 1400x1050 | | | ESGS1=1366:0768:*:**** | ✓ | | |
| | | | 1440x900 | | | ESGS1=1400:1050:*:**** | ✓ | | |
| | | | 1600x900 | | | ESGS1=1440:0900:*:**** | ✓ | | |
| | | | 1600x1200 | | | ESGS1=1600:0900:*:**** | ✓ | | |
| | | | 1600x1200 | | | ESGS1=1600:1200:*:**** | ✓ | | |
| | | | 1680x1050 | | | ESGS1=1680:1050:*:**** | ✓ | | |
| | | | 1920x1080 | | | ESGS1=1920:1080:*:**** | ✓ | | |
| | | | 1920x1200 | | | ESGS1=1920:1200:*:**** | ✓ | | |
| | | | | * PARAMETER2 | Progressive Interface | | | ESGS1=*****:p:**** | ✓ |
| | | | | * PARAMETER3 | 60Hz | | | ESGS1=*****:j:**** | ✓ |
| | | 50Hz | | | ESGS1=*****:*:6000 | ✓ | | | |
| | | 48Hz | | | ESGS1=*****:*:5000 | ✓ | | | |
| | | 30Hz | | | ESGS1=*****:*:4800 | ✓ | | | |
| | | 25Hz | | | ESGS1=*****:*:3000 | ✓ | | | |
| | | 24Hz | | | ESGS1=*****:*:2500 | ✓ | | | |
| | | | | | ESGS1=*****:*:2400 | ✓ | | | |
| HDMI IN-HDMI1 SIGNAL LEVEL | 0-1023 64-940 AUTO | | | VXX:HSLI1=+00000 VXX:HSLI1=+00001 VXX:HSLI1=+00002 | QVX:HSLI1 | HSLI1=+00000 HSLI1=+00001 HSLI1=+00002 | ✓ ✓ ✓ | | |
| HDMI IN-HDMI2 SIGNAL LEVEL | 0-1023 64-940 AUTO | | | VXX:HSLI2=+00000 VXX:HSLI2=+00001 VXX:HSLI2=+00002 | QVX:HSLI2 | HSLI2=+00000 HSLI2=+00001 HSLI2=+00002 | ✓ ✓ ✓ | | |
| HDMI IN-HDMI3 SIGNAL LEVEL | 0-1023 64-940 AUTO | | | VXX:HSLI3=+00000 VXX:HSLI3=+00001 VXX:HSLI3=+00002 | QVX:HSLI3 | HSLI3=+00000 HSLI3=+00001 HSLI3=+00002 | ✓ ✓ ✓ | | |
| HDMI IN-HDMI1 EDID SELECT | 4K/60p 4K/30p 2K | | | VXX:HESI1=+00000 VXX:HESI1=+00001 VXX:HESI1=+00002 | QVX:HESI1 | HESI1=+00000 HESI1=+00001 HESI1=+00002 | ✓ ✓ ✓ | | |
| HDMI IN-HDMI2 EDID SELECT | 4K/60p 4K/30p 2K | | | VXX:HESI2=+00000 VXX:HESI2=+00001 VXX:HESI2=+00002 | QVX:HESI2 | HESI2=+00000 HESI2=+00001 HESI2=+00002 | ✓ ✓ ✓ | | |
| HDMI IN-HDMI3 EDID SELECT | 4K/60p 4K/30p 2K | | | VXX:HESI3=+00000 VXX:HESI3=+00001 VXX:HESI3=+00002 | QVX:HESI3 | HESI3=+00000 HESI3=+00001 HESI3=+00002 | ✓ ✓ ✓ | | |
| HDMI IN-HDMI1 EDID MODE | DEFAULT SCREEN FIT USER | | | VXX:EDMI3=+00000 VXX:EDMI3=+00001 VXX:EDMI3=+00010 | QVX:EDMI3 | EDMI3=+00000 EDMI3=+00001 EDMI3=+00010 | ✓ ✓ ✓ | | |
| HDMI IN-HDMI2 EDID MODE | DEFAULT SCREEN FIT USER | | | VXX:EDMI6=+00000 VXX:EDMI6=+00001 VXX:EDMI6=+00010 | QVX:EDMI6 | EDMI6=+00000 EDMI6=+00001 EDMI6=+00010 | ✓ ✓ ✓ | | |
| HDMI IN-HDMI3 EDID MODE | DEFAULT SCREEN FIT USER | | | VXX:EDMIA=+00000 VXX:EDMIA=+00001 VXX:EDMIA=+00010 | QVX:EDMIA | EDMIA=+00000 EDMIA=+00001 EDMIA=+00010 | ✓ ✓ ✓ | | |
| HDMI IN-EDID RESOLUTION | 1024x768p 1280x720p 1280x768p 1280x800p 1280x1024p 1366x768p 1400x1050p 1440x900p 1600x900p 1600x1200p 1680x1050p 1920x1080p 1920x1080i 1920x1200p | | | VXX:EDRS3=1024:0768:p VXX:EDRS3=1280:0720:p VXX:EDRS3=1280:0768:p VXX:EDRS3=1280:0800:p VXX:EDRS3=1280:1024:p VXX:EDRS3=1366:0768:p VXX:EDRS3=1400:1050:p VXX:EDRS3=1440:0900:p VXX:EDRS3=1600:0900:p VXX:EDRS3=1600:1200:p VXX:EDRS3=1680:1050:p VXX:EDRS3=1920:1080:p VXX:EDRS3=1920:1080:i VXX:EDRS3=1920:1200:p | QVX:EDRS3 | EDRS3=1024:0768:p EDRS3=1280:0720:p EDRS3=1280:0768:p EDRS3=1280:0800:p EDRS3=1280:1024:p EDRS3=1366:0768:p EDRS3=1400:1050:p EDRS3=1440:0900:p EDRS3=1600:0900:p EDRS3=1600:1200:p EDRS3=1680:1050:p EDRS3=1920:1080:p EDRS3=1920:1080:i EDRS3=1920:1200:p | ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ | | |
| HDMI IN-HDMI2 EDID RESOLUTION | 1024x768p 1280x720p 1280x768p 1280x800p 1280x1024p 1366x768p 1400x1050p 1440x900p 1600x900p 1600x1200p 1680x1050p 1920x1080p 1920x1080i 1920x1200p | | | VXX:EDRS6=1024:0768:p VXX:EDRS6=1280:0720:p VXX:EDRS6=1280:0768:p VXX:EDRS6=1280:0800:p VXX:EDRS6=1280:1024:p VXX:EDRS6=1366:0768:p VXX:EDRS6=1400:1050:p VXX:EDRS6=1440:0900:p VXX:EDRS6=1600:0900:p VXX:EDRS6=1600:1200:p VXX:EDRS6=1680:1050:p VXX:EDRS6=1920:1080:p VXX:EDRS6=1920:1080:i VXX:EDRS6=1920:1200:p | QVX:EDRS6 | EDRS6=1024:0768:p EDRS6=1280:0720:p EDRS6=1280:0768:p EDRS6=1280:0800:p EDRS6=1280:1024:p EDRS6=1366:0768:p EDRS6=1400:1050:p EDRS6=1440:0900:p EDRS6=1600:0900:p EDRS6=1600:1200:p EDRS6=1680:1050:p EDRS6=1920:1080:p EDRS6=1920:1080:i EDRS6=1920:1200:p | ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ | | |
| HDMI IN-HDMI3 EDID RESOLUTION | 1024x768p 1280x720p 1280x768p 1280x800p 1280x1024p 1366x768p 1400x1050p 1440x900p 1600x900p 1600x1200p 1680x1050p 1920x1080p 1920x1080i 1920x1200p | | | VXX:EDRSA=1024:0768:p VXX:EDRSA=1280:0720:p VXX:EDRSA=1280:0768:p VXX:EDRSA=1280:0800:p VXX:EDRSA=1280:1024:p VXX:EDRSA=1366:0768:p VXX:EDRSA=1400:1050:p VXX:EDRSA=1440:0900:p VXX:EDRSA=1600:0900:p VXX:EDRSA=1600:1200:p VXX:EDRSA=1680:1050:p VXX:EDRSA=1920:1080:p VXX:EDRSA=1920:1080:i VXX:EDRSA=1920:1200:p | QVX:EDRSA | EDRSA=1024:0768:p EDRSA=1280:0720:p EDRSA=1280:0768:p EDRSA=1280:0800:p EDRSA=1280:1024:p EDRSA=1366:0768:p EDRSA=1400:1050:p EDRSA=1440:0900:p EDRSA=1600:0900:p EDRSA=1600:1200:p EDRSA=1680:1050:p EDRSA=1920:1080:p EDRSA=1920:1080:i EDRSA=1920:1200:p | ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ ✓ | | |
| HDMI IN-HDMI* EDID RESOLUTION | * PARAMETER | HDMI1 | | VXX:EDRS3=***:***:* | QVX:EDRS3 | EDRS3=***:***:* | ✓ | | |
| | | HDMI2 | | VXX:EDRS6=***:***:* | QVX:EDRS6 | EDRS6=***:***:* | ✓ | | |
| | | 1024x768p | | VXX:***=1024:0768:p | | ***=1024:0768:p | ✓ | | |
| | | 1280x720p | | VXX:***=1280:0720:p | | ***=1280:0720:p | ✓ | | |
| | | 1280x768p | | VXX:***=1280:0768:p | | ***=1280:0768:p | ✓ | | |
| | | 1280x800p | | VXX:***=1280:0800:p | | ***=1280:0800:p | ✓ | | |
| | | 1280x1024p | | VXX:***=1280:1024:p | | ***=1280:1024:p | ✓ | | |
| | | 1366x768p | | VXX:***=1366:0768:p | | ***=1366:0768:p | ✓ | | |
| | | 1400x1050p | | VXX:***=1400:1050:p | | ***=1400:1050:p | ✓ | | |
| | | 1440x900p | | VXX:***=1440:0900:p | | ***=1440:0900:p | ✓ | | |
| | | 1600x900p | | VXX:***=1600:0900:p | | ***=1600:0900:p | ✓ | | |
| | | 1600x1200p | | VXX:***=1600:1200:p | | ***=1600:1200:p | ✓ | | |
| | | 1680x1050p | | VXX:***=1680:1050:p | | ***=1680:1050:p | ✓ | | |
| | | 1920x1080p | | VXX:***=1920:1080:p | | ***=1920:1080:p | ✓ | | |
| | | 1920x1080i | | VXX:***=1920:1080:i | | ***=1920:1080:i | ✓ | | |
| 1920x1200p | | VXX:***=1920:1200:p | | ***=1920:1200:p | ✓ | | | | |
| HDMI IN-EDID VERTICAL SCAN FREQUENCY | 120Hz 60Hz 50Hz 48Hz 30Hz 25Hz | | | VXX:EDVI3=+12000 VXX:EDVI3=+06000 VXX:EDVI3=+05000 VXX:EDVI3=+04800 VXX:EDVI3=+03000 VXX:EDVI3=+02500 | QVX:EDVI3 | EDVI3=+12000 EDVI3=+06000 EDVI3=+05000 EDVI3=+04800 EDVI3=+03000 EDVI3=+02500 | ✓ ✓ ✓ ✓ ✓ ✓ | | |

| CATEGORY | FUNCTION | Parameter/Name | Sub-Parameter | CONTROL | | QUERY | | MZ882 SERIES |
|--|---|---|--------------------------------|--------------------------------|--------------------------------|---------------------------|---------------------------|--------------|
| | | | | COMMANDS/CALL BACK | COMMANDS | CALL BACK | | |
| DISPLAY OPTION | HDMI IN-HDMI2 EDID VERTICAL SCAN FREQUENCY | 24Hz | | VXX: EDVI3=+02400 | | EDVI3=+02400 | ✓ | |
| | | 120Hz | | VXX: EDVI6=+12000 | QVX: EDVI6 | EDVI6=+12000 | ✓ | |
| | | 60Hz | | VXX: EDVI6=+06000 | | EDVI6=+06000 | ✓ | |
| | | 50Hz | | VXX: EDVI6=+05000 | | EDVI6=+05000 | ✓ | |
| | | 48Hz | | VXX: EDVI6=+04800 | | EDVI6=+04800 | ✓ | |
| | | 30Hz | | VXX: EDVI6=+03000 | | EDVI6=+03000 | ✓ | |
| | HDMI IN-HDMI3 EDID VERTICAL SCAN FREQUENCY | 25Hz | | VXX: EDVI6=+02500 | | EDVI6=+02500 | ✓ | |
| | | 24Hz | | VXX: EDVI6=+02400 | | EDVI6=+02400 | ✓ | |
| | | 60Hz | | VXX: EDVIA=+06000 | QVX: EDVIA | EDVIA=+06000 | ✓ | |
| | | 50Hz | | VXX: EDVIA=+05000 | | EDVIA=+05000 | ✓ | |
| | | 48Hz | | VXX: EDVIA=+04800 | | EDVIA=+04800 | ✓ | |
| | | 30Hz | | VXX: EDVIA=+03000 | | EDVIA=+03000 | ✓ | |
| | HDMI IN-HDMI* EDID VERTICAL SCAN FREQUENCY | 25Hz | | VXX: EDVIA=+02500 | | EDVIA=+02500 | ✓ | |
| | | 24Hz | | VXX: EDVIA=+02400 | | EDVIA=+02400 | ✓ | |
| | | 60Hz | 60Hz | VXX: *****=+06000 | QVX: EDVI3 | *****=+06000 | ✓ | |
| | | 50Hz | 50Hz | VXX: *****=+05000 | | *****=+05000 | ✓ | |
| | | 48Hz | 48Hz | VXX: *****=+04800 | | *****=+04800 | ✓ | |
| | | 30Hz | 30Hz | VXX: *****=+03000 | | *****=+03000 | ✓ | |
| | HDMI IN-HDMI1 EDID RESOLUTION / VERTICAL SCAN FREQUENCY | * PARAMETER | | VXX: EDHS1=*****: *: ***** | QVX: EDHS1 | EDHS1=*****: *: ***** | ✓ | |
| | | | 1024x768 | VXX: EDHS1=1024:0768: *: ***** | | EDHS1=1024:0768: *: ***** | ✓ | |
| | | 1280x720 | VXX: EDHS1=1280:0720: *: ***** | | EDHS1=1280:0720: *: ***** | ✓ | | |
| | | 1280x768 | VXX: EDHS1=1280:0768: *: ***** | | EDHS1=1280:0768: *: ***** | ✓ | | |
| | | 1280x800 | VXX: EDHS1=1280:0800: *: ***** | | EDHS1=1280:0800: *: ***** | ✓ | | |
| | | 1280x1024 | VXX: EDHS1=1280:1024: *: ***** | | EDHS1=1280:1024: *: ***** | ✓ | | |
| | | 1366x768 | VXX: EDHS1=1366:0768: *: ***** | | EDHS1=1366:0768: *: ***** | ✓ | | |
| | | 1400x1050 | VXX: EDHS1=1400:1050: *: ***** | | EDHS1=1400:1050: *: ***** | ✓ | | |
| | | 1440x900 | VXX: EDHS1=1440:0900: *: ***** | | EDHS1=1440:0900: *: ***** | ✓ | | |
| | | 1600x900 | VXX: EDHS1=1600:0900: *: ***** | | EDHS1=1600:0900: *: ***** | ✓ | | |
| | | 1600x1200 | VXX: EDHS1=1600:1200: *: ***** | | EDHS1=1600:1200: *: ***** | ✓ | | |
| | | 1680x1050 | VXX: EDHS1=1680:1050: *: ***** | | EDHS1=1680:1050: *: ***** | ✓ | | |
| | | 1920x1080 | VXX: EDHS1=1920:1080: *: ***** | | EDHS1=1920:1080: *: ***** | ✓ | | |
| | | 1920x1200 | VXX: EDHS1=1920:1200: *: ***** | | EDHS1=1920:1200: *: ***** | ✓ | | |
| | | * PARAMETER2 | Progressive Interlace | VXX: EDHS1=*****: p: ***** | | EDHS1=*****: p: ***** | ✓ | |
| | | | | VXX: EDHS1=*****: j: ***** | | EDHS1=*****: j: ***** | ✓ | |
| | | | 120Hz | VXX: EDHS1=*****: *: 12000 | | EDHS1=*****: *: 12000 | ✓ | |
| | | | 60Hz | VXX: EDHS1=*****: *: 06000 | | EDHS1=*****: *: 06000 | ✓ | |
| | | | 50Hz | VXX: EDHS1=*****: *: 05000 | | EDHS1=*****: *: 05000 | ✓ | |
| | | | 48Hz | VXX: EDHS1=*****: *: 04800 | | EDHS1=*****: *: 04800 | ✓ | |
| | | | 30Hz | VXX: EDHS1=*****: *: 03000 | | EDHS1=*****: *: 03000 | ✓ | |
| | | | 25Hz | VXX: EDHS1=*****: *: 02500 | | EDHS1=*****: *: 02500 | ✓ | |
| | | | 24Hz | VXX: EDHS1=*****: *: 02400 | | EDHS1=*****: *: 02400 | ✓ | |
| | | HDMI IN-HDMI2 EDID RESOLUTION / VERTICAL SCAN FREQUENCY | * PARAMETER | | VXX: EDHS2=*****: *: ***** | QVX: EDHS2 | EDHS2=*****: *: ***** | ✓ |
| | | | | 1024x768 | VXX: EDHS2=1024:0768: *: ***** | | EDHS2=1024:0768: *: ***** | ✓ |
| | 1280x720 | | VXX: EDHS2=1280:0720: *: ***** | | EDHS2=1280:0720: *: ***** | ✓ | | |
| | 1280x768 | | VXX: EDHS2=1280:0768: *: ***** | | EDHS2=1280:0768: *: ***** | ✓ | | |
| 1280x800 | VXX: EDHS2=1280:0800: *: ***** | | | EDHS2=1280:0800: *: ***** | ✓ | | | |
| 1280x1024 | VXX: EDHS2=1280:1024: *: ***** | | | EDHS2=1280:1024: *: ***** | ✓ | | | |
| 1366x768 | VXX: EDHS2=1366:0768: *: ***** | | | EDHS2=1366:0768: *: ***** | ✓ | | | |
| 1400x1050 | VXX: EDHS2=1400:1050: *: ***** | | | EDHS2=1400:1050: *: ***** | ✓ | | | |
| 1440x900 | VXX: EDHS2=1440:0900: *: ***** | | | EDHS2=1440:0900: *: ***** | ✓ | | | |
| 1600x900 | VXX: EDHS2=1600:0900: *: ***** | | | EDHS2=1600:0900: *: ***** | ✓ | | | |
| 1600x1200 | VXX: EDHS2=1600:1200: *: ***** | | | EDHS2=1600:1200: *: ***** | ✓ | | | |
| 1680x1050 | VXX: EDHS2=1680:1050: *: ***** | | | EDHS2=1680:1050: *: ***** | ✓ | | | |
| 1920x1080 | VXX: EDHS2=1920:1080: *: ***** | | | EDHS2=1920:1080: *: ***** | ✓ | | | |
| 1920x1200 | VXX: EDHS2=1920:1200: *: ***** | | | EDHS2=1920:1200: *: ***** | ✓ | | | |
| * PARAMETER2 | Progressive Interlace | | VXX: EDHS2=*****: p: ***** | | EDHS2=*****: p: ***** | ✓ | | |
| | | | VXX: EDHS2=*****: j: ***** | | EDHS2=*****: j: ***** | ✓ | | |
| | 60Hz | | VXX: EDHS2=*****: *: 06000 | | EDHS2=*****: *: 06000 | ✓ | | |
| | 50Hz | | VXX: EDHS2=*****: *: 05000 | | EDHS2=*****: *: 05000 | ✓ | | |
| | 48Hz | | VXX: EDHS2=*****: *: 04800 | | EDHS2=*****: *: 04800 | ✓ | | |
| | 30Hz | | VXX: EDHS2=*****: *: 03000 | | EDHS2=*****: *: 03000 | ✓ | | |
| | 25Hz | | VXX: EDHS2=*****: *: 02500 | | EDHS2=*****: *: 02500 | ✓ | | |
| | 24Hz | | VXX: EDHS2=*****: *: 02400 | | EDHS2=*****: *: 02400 | ✓ | | |
| HDMI IN-HDMI3 EDID RESOLUTION / VERTICAL SCAN FREQUENCY | * PARAMETER | | | VXX: EDHS3=*****: *: ***** | QVX: EDHS3 | EDHS3=*****: *: ***** | ✓ | |
| | | | 1024x768 | VXX: EDHS3=1024:0768: *: ***** | | EDHS3=1024:0768: *: ***** | ✓ | |
| | 1280x720 | | VXX: EDHS3=1280:0720: *: ***** | | EDHS3=1280:0720: *: ***** | ✓ | | |
| | 1280x768 | VXX: EDHS3=1280:0768: *: ***** | | EDHS3=1280:0768: *: ***** | ✓ | | | |
| | 1280x800 | VXX: EDHS3=1280:0800: *: ***** | | EDHS3=1280:0800: *: ***** | ✓ | | | |
| | 1280x1024 | VXX: EDHS3=1280:1024: *: ***** | | EDHS3=1280:1024: *: ***** | ✓ | | | |
| | 1366x768 | VXX: EDHS3=1366:0768: *: ***** | | EDHS3=1366:0768: *: ***** | ✓ | | | |
| | 1400x1050 | VXX: EDHS3=1400:1050: *: ***** | | EDHS3=1400:1050: *: ***** | ✓ | | | |
| | 1440x900 | VXX: EDHS3=1440:0900: *: ***** | | EDHS3=1440:0900: *: ***** | ✓ | | | |
| | 1600x900 | VXX: EDHS3=1600:0900: *: ***** | | EDHS3=1600:0900: *: ***** | ✓ | | | |
| | 1600x1200 | VXX: EDHS3=1600:1200: *: ***** | | EDHS3=1600:1200: *: ***** | ✓ | | | |
| | 1680x1050 | VXX: EDHS3=1680:1050: *: ***** | | EDHS3=1680:1050: *: ***** | ✓ | | | |
| | 1920x1080 | VXX: EDHS3=1920:1080: *: ***** | | EDHS3=1920:1080: *: ***** | ✓ | | | |
| | 1920x1200 | VXX: EDHS3=1920:1200: *: ***** | | EDHS3=1920:1200: *: ***** | ✓ | | | |
| | * PARAMETER2 | Progressive Interlace | VXX: EDHS3=*****: p: ***** | | EDHS3=*****: p: ***** | ✓ | | |
| | | VXX: EDHS3=*****: j: ***** | | EDHS3=*****: j: ***** | ✓ | | | |
| * PARAMETER3 | 60Hz | VXX: EDHS3=*****: *: 6000 | | EDHS3=*****: *: 6000 | ✓ | | | |
| | 50Hz | VXX: EDHS3=*****: *: 5000 | | EDHS3=*****: *: 5000 | ✓ | | | |
| | 48Hz | VXX: EDHS3=*****: *: 4800 | | EDHS3=*****: *: 4800 | ✓ | | | |
| | 30Hz | VXX: EDHS3=*****: *: 3000 | | EDHS3=*****: *: 3000 | ✓ | | | |
| | 25Hz | VXX: EDHS3=*****: *: 2500 | | EDHS3=*****: *: 2500 | ✓ | | | |
| | 24Hz | VXX: EDHS3=*****: *: 2400 | | EDHS3=*****: *: 2400 | ✓ | | | |
| HDMI IN-HDMI* EDID RESOLUTION / VERTICAL SCAN FREQUENCY | HDMI1 | | VXX: EDHS1=*****: *: ***** | QVX: EDHS1 | EDHS1=*****: *: ***** | ✓ | | |
| | | HDMI2 | VXX: EDHS2=*****: *: ***** | QVX: EDHS2 | EDHS2=*****: *: ***** | ✓ | | |
| | * PARAMETER1 | 1024x768 | VXX: *****=1024:0768: *: ***** | | *****=1024:0768: *: ***** | ✓ | | |
| | | 1280x720 | VXX: *****=1280:0720: *: ***** | | *****=1280:0720: *: ***** | ✓ | | |
| | | 1280x768 | VXX: *****=1280:0768: *: ***** | | *****=1280:0768: *: ***** | ✓ | | |
| | | 1280x800 | VXX: *****=1280:0800: *: ***** | | *****=1280:0800: *: ***** | ✓ | | |
| | | 1280x1024 | VXX: *****=1280:1024: *: ***** | | *****=1280:1024: *: ***** | ✓ | | |
| | | 1366x768 | VXX: *****=1366:0768: *: ***** | | *****=1366:0768: *: ***** | ✓ | | |
| | | 1400x1050 | VXX: *****=1400:1050: *: ***** | | *****=1400:1050: *: ***** | ✓ | | |
| | | 1440x900 | VXX: *****=1440:0900: *: ***** | | *****=1440:0900: *: ***** | ✓ | | |
| | | 1600x900 | VXX: *****=1600:0900: *: ***** | | *****=1600:0900: *: ***** | ✓ | | |
| | | 1600x1200 | VXX: *****=1600:1200: *: ***** | | *****=1600:1200: *: ***** | ✓ | | |
| | | 1680x1050 | VXX: *****=1680:1050: *: ***** | | *****=1680:1050: *: ***** | ✓ | | |
| | | 1920x1080 | VXX: *****=1920:1080: *: ***** | | *****=1920:1080: *: ***** | ✓ | | |
| | | 1920x1200 | VXX: *****=1920:1200: *: ***** | | *****=1920:1200: *: ***** | ✓ | | |
| * PARAMETER2 | Progressive Interlace | VXX: *****=*****: p: ***** | | *****=*****: p: ***** | ✓ | | | |
| | | VXX: *****=*****: j: ***** | | *****=*****: j: ***** | ✓ | | | |
| * PARAMETER3 | 60Hz | VXX: *****=*****: *: 06000 | | *****=*****: *: 06000 | ✓ | | | |
| | 50Hz | VXX: *****=*****: *: 05000 | | *****=*****: *: 05000 | ✓ | | | |
| | 48Hz | VXX: *****=*****: *: 04800 | | *****=*****: *: 04800 | ✓ | | | |
| | 30Hz | VXX: *****=*****: *: 03000 | | *****=*****: *: 03000 | ✓ | | | |
| | 25Hz | VXX: *****=*****: *: 02500 | | *****=*****: *: 02500 | ✓ | | | |
| | 24Hz | VXX: *****=*****: *: 02400 | | *****=*****: *: 02400 | ✓ | | | |
| HDMI IN-HDMI1 EDID STATUS RESOLUTION / VERTICAL SCAN FREQUENCY | 1024x768 | | | QVX: ESHS1 | ESHS1=1024:0768: *: ***** | ✓ | | |
| | 1280x720 | | | | ESHS1=1280:0720: *: ***** | ✓ | | |
| | 1280x768 | | | | ESHS1=1280:0768: *: ***** | ✓ | | |
| | 1280x800 | | | | ESHS1=1280:0800: *: ***** | ✓ | | |

| CATEGORY | FUNCTION | Parameter/Name | Sub-Parameter | CONTROL | QUERY | MZ882 SERIES | | | | |
|--|-----------------------|-----------------------|---------------------------|-----------------------|---------------------|-----------------------------|-------------------------|---------------------|-----------|-------------------------|
| | | | | COMMANDS/CALL BACK | COMMANDS | | CALL BACK | | | |
| HDMI IN-HDMI* EDID STATUS RESOLUTION / VERTICAL SCAN FREQUENCY | * PARAMETER1 | | 1280x1024 | | | ESHS1=1280:1024:*:***** | ✓ | | | |
| | | | 1366x768 | | | ESHS1=1366:0768:*:***** | ✓ | | | |
| | | | 1400x1050 | | | ESHS1=1400:1050:*:***** | ✓ | | | |
| | | | 1440x900 | | | ESHS1=1440:0900:*:***** | ✓ | | | |
| | | | 1600x900 | | | ESHS1=1600:0900:*:***** | ✓ | | | |
| | | | 1600x1200 | | | ESHS1=1600:1200:*:***** | ✓ | | | |
| | | | 1680x1050 | | | ESHS1=1680:1050:*:***** | ✓ | | | |
| | | | 1920x1080 | | | ESHS1=1920:1080:*:***** | ✓ | | | |
| | | | 1920x1200 | | | ESHS1=1920:1200:*:***** | ✓ | | | |
| | * PARAMETER2 | Progressive Interlace | | | | ESHS1=*****:p:***** | ✓ | | | |
| | | | | | | ESHS1=*****:j:***** | ✓ | | | |
| | 60Hz | | | 60Hz | | | ESHS1=*****:*:06000 | ✓ | | |
| | | | | 50Hz | | | ESHS1=*****:*:05000 | ✓ | | |
| | | | | 48Hz | | | ESHS1=*****:*:04800 | ✓ | | |
| | | | | 30Hz | | | ESHS1=*****:*:03000 | ✓ | | |
| | | | | 25Hz | | | ESHS1=*****:*:02500 | ✓ | | |
| | | | | 24Hz | | | ESHS1=*****:*:02400 | ✓ | | |
| | | | | HDMI1 | HDMI2 | | | | QVX:ESHS1 | ✓ |
| | | | | | | | | | QVX:ESHS2 | ✓ |
| | | | | * PARAMETER1 | | | 1024x768 | | | *****=1024:0768:*:***** |
| | 1280x720 | | | | | | *****=1280:0720:*:***** | ✓ | | |
| | 1280x768 | | | | | | *****=1280:0768:*:***** | ✓ | | |
| | 1280x800 | | | | | | *****=1280:0800:*:***** | ✓ | | |
| | 1280x1024 | | | | | | *****=1280:1024:*:***** | ✓ | | |
| 1366x768 | | | *****=1366:0768:*:***** | | | | ✓ | | | |
| 1400x1050 | | | *****=1400:1050:*:***** | | | | ✓ | | | |
| 1440x900 | | | *****=1440:0900:*:***** | | | | ✓ | | | |
| 1600x900 | | | *****=1600:0900:*:***** | | | | ✓ | | | |
| 1600x1200 | | | *****=1600:1200:*:***** | | | | ✓ | | | |
| 1680x1050 | | | *****=1680:1050:*:***** | | | | ✓ | | | |
| 1920x1080 | | | *****=1920:1080:*:***** | | | | ✓ | | | |
| 1920x1200 | | | *****=1920:1200:*:***** | | | | ✓ | | | |
| * PARAMETER2 | Progressive Interlace | | | | | | | *****=*****:p:***** | ✓ | |
| | | | | | | | | *****=*****:j:***** | ✓ | |
| 60Hz | | | 60Hz | | | *****=*****:*:06000 | ✓ | | | |
| | | | 50Hz | | | *****=*****:*:05000 | ✓ | | | |
| | | | 48Hz | | | *****=*****:*:04800 | ✓ | | | |
| | | | 30Hz | | | *****=*****:*:03000 | ✓ | | | |
| | | | 25Hz | | | *****=*****:*:02500 | ✓ | | | |
| | | | 24Hz | | | *****=*****:*:02400 | ✓ | | | |
| | | | DIGITAL LINK-SIGNAL LEVEL | AUTO | | VXX:DKLI1=+00000 | QVX:DKLI1 | DKLI1=+00000 | ✓ | |
| | | | 0-1023 | | VXX:DKLI1=+00001 | | DKLI1=+00001 | ✓ | | |
| | | | 64-940 | | VXX:DKLI1=+00002 | | DKLI1=+00002 | ✓ | | |
| DIGITAL LINK-EDID SELECT (SINGLE LINK) | EDID1:4K/60p | | VXX:LESI1=+00000 | QVX:LESI1 | LESI1=+00000 | ✓ | | | | |
| EDID2:4K/30p | | VXX:LESI1=+00001 | | LESI1=+00001 | ✓ | | | | | |
| EDID3:2K | | VXX:LESI1=+00002 | | LESI1=+00002 | ✓ | | | | | |
| EDID4:4K/30p/HDR | | VXX:LESI1=+00011 | | LESI1=+00011 | ✓ | | | | | |
| DIGITAL LINK-EDID MODE | DEFAULT | | VXX:EDMI4=+00000 | QVX:EDMI4 | EDMI4=+00000 | ✓ | | | | |
| SCREEN FIT | | VXX:EDMI4=+00001 | | EDMI4=+00001 | ✓ | | | | | |
| USER | | VXX:EDMI4=+00010 | | EDMI4=+00010 | ✓ | | | | | |
| DIGITAL LINK-EDID RESOLUTION | 1024x768p | | VXX:EDRS4=1024:0768:p | QVX:EDRS4 | EDRS4=1024:0768:p | ✓ | | | | |
| 1280x720p | | VXX:EDRS4=1280:0720:p | | EDRS4=1280:0720:p | ✓ | | | | | |
| 1280x768p | | VXX:EDRS4=1280:0768:p | | EDRS4=1280:0768:p | ✓ | | | | | |
| 1280x800p | | VXX:EDRS4=1280:0800:p | | EDRS4=1280:0800:p | ✓ | | | | | |
| 1280x1024p | | VXX:EDRS4=1280:1024:p | | EDRS4=1280:1024:p | ✓ | | | | | |
| 1366x768p | | VXX:EDRS4=1366:0768:p | | EDRS4=1366:0768:p | ✓ | | | | | |
| 1400x1050p | | VXX:EDRS4=1400:1050:p | | EDRS4=1400:1050:p | ✓ | | | | | |
| 1440x900p | | VXX:EDRS4=1440:0900:p | | EDRS4=1440:0900:p | ✓ | | | | | |
| 1600x900p | | VXX:EDRS4=1600:0900:p | | EDRS4=1600:0900:p | ✓ | | | | | |
| 1600x1200p | | VXX:EDRS4=1600:1200:p | | EDRS4=1600:1200:p | ✓ | | | | | |
| 1680x1050p | | VXX:EDRS4=1680:1050:p | | EDRS4=1680:1050:p | ✓ | | | | | |
| 1920x1080p | | VXX:EDRS4=1920:1080:p | | EDRS4=1920:1080:p | ✓ | | | | | |
| 1920x1080i | | VXX:EDRS4=1920:1080:i | | EDRS4=1920:1080:i | ✓ | | | | | |
| 1920x1200p | | VXX:EDRS4=1920:1200:p | | EDRS4=1920:1200:p | ✓ | | | | | |
| DIGITAL LINK-EDID VERTICAL SCAN FREQUENCY | 60Hz | | VXX:EDVI4=+06000 | QVX:EDVI4 | EDVI4=+06000 | ✓ | | | | |
| 50Hz | | VXX:EDVI4=+05000 | | EDVI4=+05000 | ✓ | | | | | |
| 48Hz | | VXX:EDVI4=+04800 | | EDVI4=+04800 | ✓ | | | | | |
| 30Hz | | VXX:EDVI4=+03000 | | EDVI4=+03000 | ✓ | | | | | |
| 25Hz | | VXX:EDVI4=+02500 | | EDVI4=+02500 | ✓ | | | | | |
| 24Hz | | VXX:EDVI4=+02400 | | EDVI4=+02400 | ✓ | | | | | |
| DIGITAL LINK-EDID RESOLUTION / VERTICAL SCAN FREQUENCY | * PARAMETER | | VXX:EDLS1=*****:*:***** | QVX:EDLS1 | EDLS1=*****:*:***** | ✓ | | | | |
| * PARAMETER1 | | | 1024x768 | | | VXX:EDLS1=1024:0768:*:***** | ✓ | | | |
| | | | 1280x720 | | | VXX:EDLS1=1280:0720:*:***** | ✓ | | | |
| | | | 1280x768 | | | VXX:EDLS1=1280:0768:*:***** | ✓ | | | |
| | | | 1280x800 | | | VXX:EDLS1=1280:0800:*:***** | ✓ | | | |
| | | | 1280x1024 | | | VXX:EDLS1=1280:1024:*:***** | ✓ | | | |
| | | | 1366x768 | | | VXX:EDLS1=1366:0768:*:***** | ✓ | | | |
| | | | 1400x1050 | | | VXX:EDLS1=1400:1050:*:***** | ✓ | | | |
| | | | 1440x900 | | | VXX:EDLS1=1440:0900:*:***** | ✓ | | | |
| | | | 1600x900 | | | VXX:EDLS1=1600:0900:*:***** | ✓ | | | |
| | | | 1600x1200 | | | VXX:EDLS1=1600:1200:*:***** | ✓ | | | |
| | | | 1680x1050 | | | VXX:EDLS1=1680:1050:*:***** | ✓ | | | |
| | | | 1920x1080 | | | VXX:EDLS1=1920:1080:*:***** | ✓ | | | |
| | | | 1920x1200 | | | VXX:EDLS1=1920:1200:*:***** | ✓ | | | |
| | | | * PARAMETER2 | Progressive Interlace | | VXX:EDLS1=*****:p:***** | | EDLS1=*****:p:***** | ✓ | |
| | | | | | | VXX:EDLS1=*****:j:***** | | EDLS1=*****:j:***** | ✓ | |
| * PARAMETER3 | | | 60Hz | | | VXX:EDLS1=*****:*:6000 | ✓ | | | |
| | | | 50Hz | | | VXX:EDLS1=*****:*:5000 | ✓ | | | |
| | | | 48Hz | | | VXX:EDLS1=*****:*:4800 | ✓ | | | |
| | | | 30Hz | | | VXX:EDLS1=*****:*:3000 | ✓ | | | |
| | | | 25Hz | | | VXX:EDLS1=*****:*:2500 | ✓ | | | |
| | | | 24Hz | | | VXX:EDLS1=*****:*:2400 | ✓ | | | |
| DIGITAL LINK-EDID STATUS RESOLUTION / VERTICAL SCAN FREQUENCY | * PARAMETER | | | QVX:ESLS1 | ESLS1=*****:*:***** | ✓ | | | | |
| * PARAMETER1 | | | 1024x768 | | | ESLS1=1024:0768:*:***** | ✓ | | | |
| | | | 1280x720 | | | ESLS1=1280:0720:*:***** | ✓ | | | |
| | | | 1280x768 | | | ESLS1=1280:0768:*:***** | ✓ | | | |
| | | | 1280x800 | | | ESLS1=1280:0800:*:***** | ✓ | | | |
| | | | 1280x1024 | | | ESLS1=1280:1024:*:***** | ✓ | | | |
| | | | 1366x768 | | | ESLS1=1366:0768:*:***** | ✓ | | | |
| | | | 1400x1050 | | | ESLS1=1400:1050:*:***** | ✓ | | | |
| | | | 1440x900 | | | ESLS1=1440:0900:*:***** | ✓ | | | |
| | | | 1600x900 | | | ESLS1=1600:0900:*:***** | ✓ | | | |
| | | | 1600x1200 | | | ESLS1=1600:1200:*:***** | ✓ | | | |
| | | | 1680x1050 | | | ESLS1=1680:1050:*:***** | ✓ | | | |
| | | | 1920x1080 | | | ESLS1=1920:1080:*:***** | ✓ | | | |
| | | | 1920x1200 | | | ESLS1=1920:1200:*:***** | ✓ | | | |
| | | | * PARAMETER2 | Progressive Interlace | | | | ESLS1=*****:p:***** | ✓ | |
| | | | | | | | | ESLS1=*****:j:***** | ✓ | |
| * PARAMETER3 | | | 60Hz | | | ESLS1=*****:*:6000 | ✓ | | | |
| | | | 50Hz | | | ESLS1=*****:*:5000 | ✓ | | | |
| | | | 48Hz | | | ESLS1=*****:*:4800 | ✓ | | | |
| | | | 30Hz | | | ESLS1=*****:*:3000 | ✓ | | | |
| | | | 25Hz | | | ESLS1=*****:*:2500 | ✓ | | | |
| | | | 24Hz | | | ESLS1=*****:*:2400 | ✓ | | | |

| CATEGORY | FUNCTION | Parameter/Name | Sub-Parameter | CONTROL | QUERY | | MZ882 SERIES |
|---|---|----------------------|------------------------|-------------------------|------------------|-----------------|--------------|
| | | | | COMMANDS/CALL BACK | COMMANDS | CALL BACK | |
| MULTI PROJECTOR SYNC - MODE | MULTI PROJECTOR SYNC - MODE | OFF | | VXX:MPSI1=+00000 | QVX:MPSI1 | MPSI1=+00000 | ✓ |
| | | MAIN | | VXX:MPSI1=+00001 | | MPSI1=+00001 | ✓ |
| | | SUB | | VXX:MPSI1=+00002 | | MPSI1=+00002 | ✓ |
| | MULTI PROJECTOR SYNC - LINK STATUS | NO LINK | | | QVX:MPSI2 | MPSI2=+00000 | ✓ |
| | | LINKED | | | | MPSI2=+00001 | ✓ |
| | FRAME SYNC SETTING(MULTI PROJECTOR SYNC) - CONTRAST SYNC. | OFF | | VXX:CSYI1=+00000 | QVX:CSYI1 | CSYI1=+00000 | ✓ |
| | | ON | | VXX:CSYI1=+00001 | | CSYI1=+00001 | ✓ |
| | MULTI PROJECTOR SYNC - SHUTTER SYNC. | OFF | | VXX:SSYI1=+00000 | QVX:SSYI1 | SSYI1=+00000 | ✓ |
| | | ON | | VXX:SSYI1=+00001 | | SSYI1=+00001 | ✓ |
| | INPUT GUIDE | OFF | | OID:0 | QDI | 0 | ✓ |
| ON (SIMPLE) | | | OID:1 | | 1 | ✓ | |
| OSD POSITION | UPPER LEFT | | ODP:1 | QDP | 1 | ✓ | |
| | CETRE LEFT | | ODP:2 | | 2 | ✓ | |
| | LOWER LEFT | | ODP:3 | | 3 | ✓ | |
| | TOP CENTER | | ODP:4 | | 4 | ✓ | |
| | CENTER | | ODP:5 | | 5 | ✓ | |
| | LOEER CENTER | | ODP:6 | | 6 | ✓ | |
| | UPPER RIGHT | | ODP:7 | | 7 | ✓ | |
| | CENTER RIGHT | | ODP:8 | | 8 | ✓ | |
| | LOWER RIGHT | | ODP:9 | | 9 | ✓ | |
| OSD ROTATION | OFF | | VXX:OSRI1=+00000 | QVX:OSRI1 | OSRI1=+00000 | ✓ | |
| | CLOCKWISE | | VXX:OSRI1=+00001 | | OSRI1=+00001 | ✓ | |
| | COUNTER CLOCKWISE | | VXX:OSRI1=+00002 | | OSRI1=+00002 | ✓ | |
| OSD MEMORY | OFF | | VXX:OMYI0=+00000 | QVX:OMYI0 | OMYI0=+00000 | ✓ | |
| | ON | | VXX:OMYI0=+00001 | | OMYI0=+00001 | ✓ | |
| ON SCREEN | OFF | | OOS:0 | QOS | 0 | ✓ | |
| | ON | | OOS:1 | | 1 | ✓ | |
| OSD SIZE | NORMAL | | VXX:OSZI1=+00100 | QVX:OSZI1 | OSZI1=+00100 | ✓ | |
| | DOUBLE | | VXX:OSZI1=+00200 | | OSZI1=+00200 | ✓ | |
| WARNING MESSAGE | OFF | | VXX:WMDI0=+00000 | QVX:WMDI0 | WMDI0=+00000 | ✓ | |
| | ON | | VXX:WMDI0=+00001 | | WMDI0=+00001 | ✓ | |
| OSD DESIGN | 1(YELLOW) | | MOD:0 | QOD | 0 | ✓ | |
| | 2(BLUE) | | MOD:1 | | 1 | ✓ | |
| | 3(WHITE) | | MOD:2 | | 2 | ✓ | |
| | 4(GREEN) | | MOD:3 | | 3 | ✓ | |
| | 5(PEACH) | | MOD:4 | | 4 | ✓ | |
| | 6(BROWN) | | MOD:5 | | 5 | ✓ | |
| SCREEN SETTING | 16:10 | | VSF:0 | QSF | 0 | ✓ | |
| | 16:9 | | VSF:1 | | 1 | ✓ | |
| | 4:3 | | VSF:2 | | 2 | ✓ | |
| | 21:9 | | VSF:4 | | 4 | ✓ | |
| SCREEN POSITION-VERTICAL | min. | | VXX:VSPI0=-00120 | QVX:VSPI0 | VSPI0=-00120 | -60 | |
| | max. | | VXX:VSPI0=+00120 | | VSPI0=+00120 | 60 | |
| SCREEN POSITION-HORIZONTAL | min. | | VXX:HSPI0=-00320 | QVX:HSPI0 | HSPI0=-00320 | -160 | |
| | max. | | VXX:HSPI0=+00320 | | HSPI0=+00320 | +160 | |
| STARTUP LOGO | OFF | | MLO:0 | QLO | 0 | ✓ | |
| | USER LOGO | | MLO:1 | | 1 | ✓ | |
| | DEFAULT LOGO | | MLO:2 | | 2 | ✓ | |
| UNIFORMITY-USER CORRECTION * | OFF | | VXX:UFMI1=+00000 | QVX:UFMI1 | UFMI1=+00000 | ✓ | |
| | ON(PC) | | VXX:UFMI1=+00001 | | UFMI1=+00001 | ✓ | |
| UNIFORMITY - USER CORRECTION - ADJUSTMENT LEVEL | min. | | VXX:UFMI4=+00001 | QVX:UFMI4 | UFMI4=+00001 | ✓ | |
| | max. | | VXX:UFMI4=+00007 | | UFMI4=+00007 | ✓ | |
| UNIFORMITY - USER CORRECTION - TEST PATTERN | OFF | | VXX:UFMI5=+00000 | QVX:UFMI5 | UFMI5=+00000 | ✓ | |
| | ON | | VXX:UFMI5=+00001 | | UFMI5=+00001 | ✓ | |
| UNIFORMITY - USER CORRECTION - ADJUSTMENT POSITION | * PARAMETER | | VXX:UFMS6=*:*:***** | QVX:UFMS6=*:*: | UFMS6=*:*:***** | ✓ | |
| | * PARAMETER1 | UPPER LEFT | | VXX:UFMS6=0:*:***** | | UFMS6=0:*:***** | ✓ |
| | | UPPER RIGHT | | VXX:UFMS6=1:*:***** | | UFMS6=1:*:***** | ✓ |
| | | LOWER LEFT | | VXX:UFMS6=2:*:***** | | UFMS6=2:*:***** | ✓ |
| | | LOWER RIGHT | | VXX:UFMS6=3:*:***** | | UFMS6=3:*:***** | ✓ |
| | | UPPER | | VXX:UFMS6=4:*:***** | | UFMS6=4:*:***** | ✓ |
| | | LOWER | | VXX:UFMS6=5:*:***** | | UFMS6=5:*:***** | ✓ |
| | | LEFT | | VXX:UFMS6=6:*:***** | | UFMS6=6:*:***** | ✓ |
| | RIGHT | | VXX:UFMS6=7:*:***** | | UFMS6=7:*:***** | ✓ | |
| | * PARAMETER2 | RED | | VXX:UFMS6=*:R:***** | | UFMS6=*:R:***** | ✓ |
| GREEN | | | VXX:UFMS6=*:G:***** | | UFMS6=*:G:***** | ✓ | |
| BLUE | | | VXX:UFMS6=*:B:***** | | UFMS6=*:B:***** | ✓ | |
| * PARAMETER3 | min. | | VXX:UFMS6=*:*:-00031 | | UFMS6=*:*:-00031 | ✓ | |
| | 0 | | VXX:UFMS6=*:*:+00000 | | UFMS6=*:*:+00000 | ✓ | |
| max. | | VXX:UFMS6=*:*:+00031 | | UFMS6=*:*:+00031 | ✓ | | |
| UNIFORMITY - USER CORRECTION - ADJUSTMENT POSITION - INITIALIZE | EXECUTE | | VXX:UFMI7=+00001 | | | ✓ | |
| UNIFORMITY-WHITE/RED/GREEN/RED | * PARAMETER | | E\$W:* ,**** ,**** ,** | E\$R:* ,** | ** ,**** ,**** | ✓ | |
| | * PARAMETER 1 | WHITE | | E\$W:W ,**** ,**** ,** | E\$R:W ,** | ** ,**** ,**** | ✓ |
| | | RED | | E\$W:R ,**** ,**** ,** | E\$R:R ,** | ** ,**** ,**** | ✓ |
| | | GREEN | | E\$W:G ,**** ,**** ,** | E\$R:G ,** | ** ,**** ,**** | ✓ |
| | | BLUE | | E\$W:B ,**** ,**** ,** | E\$R:B ,** | ** ,**** ,**** | ✓ |
| | * PARAMETER 2 | VERTICAL(-127) | | E\$W:* , -127 ,**** ,** | E\$R:* ,** | ** , -127 ,**** | ✓ |
| | | VERTICAL(+127) | | E\$W:* , +127 ,**** ,** | E\$R:* ,** | ** , +127 ,**** | ✓ |
| | * PARAMETER 3 | HORIZONTAL(-127) | | E\$W:* ,**** , -127 ,** | E\$R:* ,** | ** ,**** , -127 | ✓ |
| | | HOROZONTAL(+127) | | E\$W:* ,**** , +127 ,** | E\$R:* ,** | ** ,**** , +127 | ✓ |
| | * PARAMETER 4 | L1(OFF) | | E\$W:* ,**** ,**** ,0* | E\$R:* ,0* | 0* ,**** ,**** | ✓ |
| | | L1(ON) | | E\$W:* ,**** ,**** ,1* | E\$R:* ,1* | 1* ,**** ,**** | ✓ |
| | | L2(OFF) | | E\$W:* ,**** ,**** ,*0 | E\$R:* ,*0 | *0 ,**** ,**** | ✓ |
| | | L2(ON) | | E\$W:* ,**** ,**** ,*1 | E\$R:* ,*1 | *1 ,**** ,**** | ✓ |
| | * PARAMETER | | E\$W:* ,**** ,**** | E\$R:* | ** ,**** ,**** | ✓ | |
| | * PARAMETER 1 | WHITE | | E\$W:W ,**** ,**** | E\$R:W | ** ,**** ,**** | ✓ |
| RED | | | E\$W:R ,**** ,**** | E\$R:R | ** ,**** ,**** | ✓ | |
| GREEN | | | E\$W:G ,**** ,**** | E\$R:G | ** ,**** ,**** | ✓ | |
| BLUE | | | E\$W:B ,**** ,**** | E\$R:B | ** ,**** ,**** | ✓ | |
| * PARAMETER 2 | VERTICAL(-127) | | E\$W:* , -127 ,**** | | ** , -127 ,**** | ✓ | |
| | VERTICAL(+127) | | E\$W:* , +127 ,**** | | ** , +127 ,**** | ✓ | |
| * PARAMETER 3 | HORIZONTAL(-127) | | E\$W:* ,**** , -127 | | ** ,**** , -127 | ✓ | |
| | HOROZONTAL(+127) | | E\$W:* ,**** , +127 | | ** ,**** , +127 | ✓ | |
| * PARAMETER 4 | L1(OFF) | | | | 0* ,**** ,**** | ✓ | |
| | L1(ON) | | | | 1* ,**** ,**** | ✓ | |
| | L2(OFF) | | | | *0 ,**** ,**** | ✓ | |
| | L2(ON) | | | | *1 ,**** ,**** | ✓ | |
| SHUTTER SETTING-FADE IN | 0.0s(OFF) | | VXX:SEFS1=0.0 | QVX:SEFS1 | SEFS1=0.0 | ✓ | |
| | 0.5s | | VXX:SEFS1=0.5 | | SEFS1=0.5 | ✓ | |
| | 1.0s | | VXX:SEFS1=1.0 | | SEFS1=1.0 | ✓ | |
| | 1.5s | | VXX:SEFS1=1.5 | | SEFS1=1.5 | ✓ | |
| | 2.0s | | VXX:SEFS1=2.0 | | SEFS1=2.0 | ✓ | |
| | 2.5s | | VXX:SEFS1=2.5 | | SEFS1=2.5 | ✓ | |
| | 3.0s | | VXX:SEFS1=3.0 | | SEFS1=3.0 | ✓ | |
| | 3.5s | | VXX:SEFS1=3.5 | | SEFS1=3.5 | ✓ | |
| | 4.0s | | VXX:SEFS1=4.0 | | SEFS1=4.0 | ✓ | |
| | 5.0s | | VXX:SEFS1=5.0 | | SEFS1=5.0 | ✓ | |
| | 7.0s | | VXX:SEFS1=7.0 | | SEFS1=7.0 | ✓ | |
| 10.0s | | VXX:SEFS1=10.0 | | SEFS1=10.0 | ✓ | | |
| SHUTTER SETTING-FADE OUT | 0.0s(OFF) | | VXX:SEFS2=0.0 | QVX:SEFS2 | SEFS2=0.0 | ✓ | |
| | 0.5s | | VXX:SEFS2=0.5 | | SEFS2=0.5 | ✓ | |
| | 1.0s | | VXX:SEFS2=1.0 | | SEFS2=1.0 | ✓ | |
| | 1.5s | | VXX:SEFS2=1.5 | | SEFS2=1.5 | ✓ | |
| | 2.0s | | VXX:SEFS2=2.0 | | SEFS2=2.0 | ✓ | |

| CATEGORY | FUNCTION | Parameter/Name | Sub-Parameter | CONTROL | QUERY | | MZ882 SERIES |
|--|--------------------------------|--------------------|--------------------|--------------------|----------------|----------------|--------------|
| | | | | COMMANDS/CALL BACK | COMMANDS | CALL BACK | |
| | | 2.5s | | VXX:SEFS2=2.5 | | SEFS2=2.5 | ✓ |
| | | 3.0s | | VXX:SEFS2=3.0 | | SEFS2=3.0 | ✓ |
| | | 3.5s | | VXX:SEFS2=3.5 | | SEFS2=3.5 | ✓ |
| | | 4.0s | | VXX:SEFS2=4.0 | | SEFS2=4.0 | ✓ |
| | | 5.0s | | VXX:SEFS2=5.0 | | SEFS2=5.0 | ✓ |
| | | 7.0s | | VXX:SEFS2=7.0 | | SEFS2=7.0 | ✓ |
| | | 10.0s | | VXX:SEFS2=10.0 | | SEFS2=10.0 | ✓ |
| | SHUTTER SETTING-STARTUP | OPEN | | VXX:SEFI3=+00000 | QVX:SEFI3 | SEFI3=+00000 | ✓ |
| | | CLOSE | | VXX:SEFI3=+00001 | | SEFI3=+00001 | ✓ |
| | SHUTTER SETTING-SHUT OFF | OPEN | | VXX:SEFI4=+00000 | QVX:SEFI4 | SEFI4=+00000 | ✓ |
| | | CLOSE | | VXX:SEFI4=+00001 | | SEFI4=+00001 | ✓ |
| | | KEEP CURRENT STATE | | VXX:SEFI4=+00002 | | SEFI4=+00002 | ✓ |
| | SIGNAL SEARCH | OFF | | OSR:0 | QSR | 0 | ✓ |
| | | ON | | OSR:1 | | 1 | ✓ |
| | BACK COLOR | BLUE | | OBC:0 | QBC | 0 | ✓ |
| | | BLACK | | OBC:1 | | 1 | ✓ |
| | | DEFAULT LOGO | | OBC:2 | | 2 | ✓ |
| | | USER LOGO | | OBC:3 | | 3 | ✓ |
| | P-TIMER-MODE | COUNT DOWN | | VXX:PTMI1=+00000 | QVX:PTMI1 | PTMI1=+00000 | ✓ |
| | | COUNT UP | | VXX:PTMI1=+00001 | | PTMI1=+00001 | ✓ |
| | P-TIMER-COUNT DOWN TIMER | 1 MIN. | | VXX:PTMI2=+00001 | QVX:PTMI2 | PTMI2=+00001 | ✓ |
| | | 180 MIN. | | VXX:PTMI2=+00180 | | PTMI2=+00180 | ✓ |
| | P-TIMER-RESET | RESET | | VXX:PTMI3=+00000 | | | ✓ |
| | P-TIMER-EXIT | EXIT | | VXX:PTMI4=+00000 | | | ✓ |
| | STATUS | | | STS | | | ✓ |
| | PROJECTOR ID | 0(ALL) | | RIS:00 | | | ✓ |
| | | 64 | | RIS:64 | | | ✓ |
| | PROJECTION METHOD INSTALLATION | FRONT/DESK | | OIL:0 | QSP | 0 | ✓ |
| REAR/DESK | | | OIL:1 | | 1 | ✓ | |
| FRONT/CEILING | | | OIL:2 | | 2 | ✓ | |
| REAR/CEILING | | | OIL:3 | | 3 | ✓ | |
| FRONT/AUTO | | | OIL:4 | | 4 | ✓ | |
| REAR/AUTO | | | OIL:5 | | 5 | ✓ | |
| PROJECTION METHOD(AUTO) | FRONT/DESK | | | QVX:PJMI2 | PJMI2=+00000 | ✓ | |
| | REAR/DESK | | | | PJMI2=+00001 | ✓ | |
| | FRONT/CEILING | | | | PJMI2=+00002 | ✓ | |
| | REAR/CEILING | | | | PJMI2=+00003 | ✓ | |
| AUTO COOLING CONDITION-STATUS | FLOOR | | | QVX:ADRI1 | ADRI1=+00000 | ✓ | |
| | CEILING | | | | ADRI1=+00001 | ✓ | |
| | VERTICAL UP | | | | ADRI1=+00002 | ✓ | |
| | VERTICAL DOWN | | | | ADRI1=+00003 | ✓ | |
| | PORTRAIT | | | | ADRI1=+00004 | ✓ | |
| LIGHT POWER | NORMAL | | VXX:LPWI1=+00000 | QLP | LPWI1=+00000 | ✓ | |
| | ECO | | VXX:LPWI1=+00001 | | LPWI1=+00001 | ✓ | |
| | QUIET | | VXX:LPWI1=+00040 | | LPWI1=+00040 | ✓ | |
| | USER | | VXX:LPWI1=+00100 | | LPWI1=+00100 | ✓ | |
| LIGHT OUTPUT | min. | | VXX:LOPI2=+00050 | QVX:LOPI2 | LOPI2=+00050 | 50% | |
| | max. | | VXX:LOPI2=+01000 | | LOPI2=+01000 | 100% | |
| ECO MANAGEMENT-AMBIENT LIGHT DETECTION | OFF | | VXX:ECO1=+00000 | QVX:ECO1 | ECO1=+00000 | ✓ | |
| | ON | | VXX:ECO1=+00001 | | ECO1=+00001 | ✓ | |
| ECO MANAGEMENT-SIGNAL DETECTION | OFF | | VXX:ECO2=+00000 | QVX:ECO2 | ECO2=+00000 | ✓ | |
| | ON | | VXX:ECO2=+00001 | | ECO2=+00001 | ✓ | |
| STANDBY MODE | NORMAL | | VXX:STMI0=+00000 | QVX:STMI0 | STMI0=+00000 | ✓ | |
| | ECO | | VXX:STMI0=+00003 | | STMI0=+00003 | ✓ | |
| AUTO POWER ON | OFF | | VXX:APOS1=OFF | QVX:APOS1 | APOS1=OFF | ✓ | |
| | COMPUTER | | VXX:APOS1=RG1 | | APOS1=RG1 | ✓ | |
| | HD1 | | VXX:APOS1=HD1 | | APOS1=HD1 | ✓ | |
| | HD2 | | VXX:APOS1=HD2 | | APOS1=HD2 | ✓ | |
| | HD3 | | VXX:APOS1=HD3 | | APOS1=HD3 | ✓ | |
| QUICK STARTUP | OFF | | VXX:QSUI1=+00000 | QVX:QSUI1 | QSUI1=+00000 | ✓ | |
| | ON | | VXX:QSUI1=+00001 | | QSUI1=+00001 | ✓ | |
| QUICK STARTUP-VALID PERIOD | 30MIN. | | VXX:QSUI2=+00030 | QVX:QSUI2 | QSUI2=+00030 | ✓ | |
| | 60MIN. | | VXX:QSUI2=+00060 | | QSUI2=+00060 | ✓ | |
| | 90MIN. | | VXX:QSUI2=+00090 | | QSUI2=+00090 | ✓ | |
| SCHEDULE | OFF | | VXX:SCHIO=+00000 | QVX:SCHIO | SCHIO=+00000 | ✓ | |
| | ON | | VXX:SCHIO=+00001 | | SCHIO=+00001 | ✓ | |
| SCHEDULE-PROGRAM ASSIGN | OFF | | VXX:SPGI*=+00000 | QVX:SPGI* | SPGI*=+00000 | ✓ | |
| | PROGRAM1 | | VXX:SPGI*=+00001 | | SPGI*=+00001 | ✓ | |
| | PROGRAM2 | | VXX:SPGI*=+00002 | | SPGI*=+00002 | ✓ | |
| | PROGRAM3 | | VXX:SPGI*=+00003 | | SPGI*=+00003 | ✓ | |
| | PROGRAM4 | | VXX:SPGI*=+00004 | | SPGI*=+00004 | ✓ | |
| | PROGRAM5 | | VXX:SPGI*=+00005 | | SPGI*=+00005 | ✓ | |
| | PROGRAM6 | | VXX:SPGI*=+00006 | | SPGI*=+00006 | ✓ | |
| | PROGRAM7 | | VXX:SPGI*=+00007 | | SPGI*=+00007 | ✓ | |
| | * PARAMETER | SUN | | VXX:SPGI0=+0000* | QVX:SPGI0 | SPGI0=+0000* | ✓ |
| | | MON | | VXX:SPGI1=+0000* | QVX:SPGI1 | SPGI1=+0000* | ✓ |
| | | TUE | | VXX:SPGI2=+0000* | QVX:SPGI2 | SPGI2=+0000* | ✓ |
| | | WED | | VXX:SPGI3=+0000* | QVX:SPGI3 | SPGI3=+0000* | ✓ |
| | | THU | | VXX:SPGI4=+0000* | QVX:SPGI4 | SPGI4=+0000* | ✓ |
| | | FRI | | VXX:SPGI5=+0000* | QVX:SPGI5 | SPGI5=+0000* | ✓ |
| SAT | | VXX:SPGI6=+0000* | QVX:SPGI6 | SPGI6=+0000* | ✓ | | |
| SCHEDULE-COMMAND SETTING | STANDBY | | VXX:SCCS*=**10**** | QVX:SCCS*=** | SCCS*=**10**** | ✓ | |
| | POWER ON | | VXX:SCCS*=**11**** | | SCCS*=**11**** | ✓ | |
| | SHUTTER OPEN | | VXX:SCCS*=**20**** | | SCCS*=**20**** | ✓ | |
| | SHUTTER CLOSE | | VXX:SCCS*=**21**** | | SCCS*=**21**** | ✓ | |
| | RGB1 INPUT | | VXX:SCCS*=**31**** | | SCCS*=**31**** | ✓ | |
| | HDMI1 INPUT | | VXX:SCCS*=**53**** | | SCCS*=**53**** | ✓ | |
| | HDMI2 INPUT | | VXX:SCCS*=**54**** | | SCCS*=**54**** | ✓ | |
| | HDMI3 INPUT | | VXX:SCCS*=**55**** | | SCCS*=**55**** | ✓ | |
| | NORMAL | | VXX:SCCS*=**70**** | | SCCS*=**70**** | ✓ | |
| | ECO | | VXX:SCCS*=**71**** | | SCCS*=**71**** | ✓ | |
| | USER1(USER) | | VXX:SCCS*=**75**** | | SCCS*=**75**** | ✓ | |
| | SILENT | | VXX:SCCS*=**78**** | | SCCS*=**78**** | ✓ | |
| | DIGITAL LINK | | VXX:SCCS*=**B0**** | | SCCS*=**B0**** | ✓ | |
| | INPUT 1 | | VXX:SCCS*=**B1**** | | SCCS*=**B1**** | ✓ | |
| | INPUT 2 | | VXX:SCCS*=**B2**** | | SCCS*=**B2**** | ✓ | |
| | INPUT 3 | | VXX:SCCS*=**B3**** | | SCCS*=**B3**** | ✓ | |
| | INPUT 4 | | VXX:SCCS*=**B4**** | | SCCS*=**B4**** | ✓ | |
| | INPUT 5 | | VXX:SCCS*=**B5**** | | SCCS*=**B5**** | ✓ | |
| | INPUT 6 | | VXX:SCCS*=**B6**** | | SCCS*=**B6**** | ✓ | |
| | INPUT 7 | | VXX:SCCS*=**B7**** | | SCCS*=**B7**** | ✓ | |
| | INPUT 8 | | VXX:SCCS*=**B8**** | | SCCS*=**B8**** | ✓ | |
| | INPUT 9 | | VXX:SCCS*=**B9**** | | SCCS*=**B9**** | ✓ | |
| | INPUT 10 | | VXX:SCCS*=**BA**** | | SCCS*=**BA**** | ✓ | |
| | AUDIO IN STANDBY OFF | | VXX:SCCS*=**A0**** | | SCCS*=**A0**** | ✓ | |
| | AUDIO IN STANDBY ON | | VXX:SCCS*=**A1**** | | SCCS*=**A1**** | ✓ | |
| | QUICK STARTUP OFF | | VXX:SCCS*=**A2**** | | SCCS*=**A2**** | ✓ | |
| | QUICK STARTUP ON | | VXX:SCCS*=**A3**** | | SCCS*=**A3**** | ✓ | |
| | AUDIO VOLUME | 0 | | VXX:SCCS*=**C0**** | | SCCS*=**C0**** | ✓ |
| | | 63 | | VXX:SCCS*=**FF**** | | SCCS*=**FF**** | ✓ |
| | * PARAMETER1 | PROGRAM1 | | VXX:SCCS1=***** | QVX:SCCS1=** | SCCS1=***** | ✓ |
| | | PROGRAM2 | | VXX:SCCS2=***** | QVX:SCCS2=** | SCCS2=***** | ✓ |
| | | PROGRAM3 | | VXX:SCCS3=***** | QVX:SCCS3=** | SCCS3=***** | ✓ |
| | | PROGRAM4 | | VXX:SCCS4=***** | QVX:SCCS4=** | SCCS4=***** | ✓ |

| CATEGORY | FUNCTION | Parameter/Name | Sub-Parameter | CONTROL | QUERY | | MZ882 SERIES |
|-------------------------------------|-------------------------------------|----------------|----------------------|--------------------|------------------|----------------|--------------|
| | | | | COMMANDS/CALL BACK | COMMANDS | CALL BACK | |
| PROJECTOR SETUP | | | PROGRAM5 | VXX:SCCS5=***** | QVX:SCCS5=** | SCCS5=***** | ✓ |
| | | | PROGRAM6 | VXX:SCCS6=***** | QVX:SCCS6=** | SCCS6=***** | ✓ |
| | | | PROGRAM7 | VXX:SCCS7=***** | QVX:SCCS7=** | SCCS7=***** | ✓ |
| | | * PARAMETER2 | COMMAND 1 | VXX:SCCS*=01***** | QVX:SCCS*=01 | SCCS*=01***** | ✓ |
| | | | COMMAND 16 | VXX:SCCS*=16***** | QVX:SCCS*=16 | SCCS*=16***** | ✓ |
| | | * PARAMETER3 | 00:00 | VXX:SCCS*=***0000 | | SCCS*=***0000 | ✓ |
| | | | 23:59 | VXX:SCCS*=***2359 | | SCCS*=***2359 | ✓ |
| | STARTUP INPUT SELECT | RGB1 | | VXX:SISI1=RG1 | QVX:SISI1 | SISI1=RG1 | ✓ |
| | | HDMI1 | | VXX:SISI1=HD1 | | SISI1=HD1 | ✓ |
| | | HDMI2 | | VXX:SISI1=HD2 | | SISI1=HD2 | ✓ |
| | | HDMI3 | | VXX:SISI1=HD3 | | SISI1=HD3 | ✓ |
| | | DIGITAL LINK | | VXX:SISI1=DL1 | | SISI1=DL1 | ✓ |
| | | LAST USED | | VXX:SISI1=LSU | | SISI1=LSU | ✓ |
| | STARTUP INPUT SELECT (DIGITAL LINK) | LAST USED | | VXX:SISI2=+00000 | QVX:SISI2 | SISI2=+00000 | ✓ |
| | | INPUT1 | | VXX:SISI2=+00001 | | SISI2=+00001 | ✓ |
| | | INPUT2 | | VXX:SISI2=+00002 | | SISI2=+00002 | ✓ |
| | | INPUT3 | | VXX:SISI2=+00003 | | SISI2=+00003 | ✓ |
| | | INPUT4 | | VXX:SISI2=+00004 | | SISI2=+00004 | ✓ |
| | | INPUT5 | | VXX:SISI2=+00005 | | SISI2=+00005 | ✓ |
| | | INPUT6 | | VXX:SISI2=+00006 | | SISI2=+00006 | ✓ |
| | | INPUT7 | | VXX:SISI2=+00007 | | SISI2=+00007 | ✓ |
| | | INPUT8 | | VXX:SISI2=+00008 | | SISI2=+00008 | ✓ |
| | | INPUT9 | | VXX:SISI2=+00009 | | SISI2=+00009 | ✓ |
| | | INPIT10 | | VXX:SISI2=+00010 | | SISI2=+00010 | ✓ |
| | NO SIGNAL SHUT-OFF | DISABLE | | OAF:00 | QAF | 00 | ✓ |
| | | 10min | | OAF:10 | | 10 | ✓ |
| | | 20min | | OAF:20 | | 20 | ✓ |
| | | 30min | | OAF:30 | | 30 | ✓ |
| | | 40min | | OAF:40 | | 40 | ✓ |
| | | 50min | | OAF:50 | | 50 | ✓ |
| | | 60min | | OAF:60 | | 60 | ✓ |
| | | 70min | | OAF:70 | | 70 | ✓ |
| | | 80min | | OAF:80 | | 80 | ✓ |
| | | 90min | | OAF:90 | | 90 | ✓ |
| | NO SIGNAL LIGHTS-OUT | DISABLE | | VXX:SLOI1=+00000 | QVX:SLOI1 | SLOI1=+00000 | ✓ |
| | | 10SEC. | | VXX:SLOI1=+00010 | | SLOI1=+00010 | ✓ |
| | | 20SEC. | | VXX:SLOI1=+00020 | | SLOI1=+00020 | ✓ |
| | | 30SEC. | | VXX:SLOI1=+00030 | | SLOI1=+00030 | ✓ |
| | | 1MIN. | | VXX:SLOI1=+00060 | | SLOI1=+00060 | ✓ |
| | | 2MIN. | | VXX:SLOI1=+00120 | | SLOI1=+00120 | ✓ |
| | | 3MIN. | | VXX:SLOI1=+00180 | | SLOI1=+00180 | ✓ |
| | | 5MIN. | | VXX:SLOI1=+00300 | | SLOI1=+00300 | ✓ |
| | REMOTE2 - MODE | DEFAULT | | VXX:RMPI0=+00000 | QVX:RMPI0 | RMPI0=+00000 | ✓ |
| | | USER | | VXX:RMPI0=+00001 | | RMPI0=+00001 | ✓ |
| | | F/FW SERIES | | VXX:RMPI0=+00003 | | RMPI0=+00003 | ✓ |
| | REMOTE2 - PIN2 | NONE | | VXX:RMPS1=P2<NONE | QVX:RMPS1=P2 | RMPS1=P2<NONE | ✓ |
| | | POWER | | VXX:RMPS1=P2<POWER | | RMPS1=P2<POWER | ✓ |
| | REMOTE2 - PIN3 - 7 | * PARAMETER | | VXX:RMPS1=P*<***** | QVX:RMPS1=P* | | ✓ |
| | | * PARAMETER1 | PIN3 | VXX:RMPS1=P3<***** | | RMPS1=P3<***** | ✓ |
| | | | PIN4 | VXX:RMPS1=P4<***** | | RMPS1=P4<***** | ✓ |
| | | | PIN5 | VXX:RMPS1=P5<***** | | RMPS1=P5<***** | ✓ |
| | | PIN6 | VXX:RMPS1=P6<***** | | RMPS1=P6<***** | ✓ | |
| | | PIN7 | VXX:RMPS1=P7<***** | | RMPS1=P7<***** | ✓ | |
| | * PARAMETER2 | NONE | VXX:RMPS1=P*<NONE | | RMPS1=P*<NONE | ✓ | |
| | | RGB1 | VXX:RMPS1=P*<RGB1 | | RMPS1=P*<RGB1 | ✓ | |
| | | HDMI1 | VXX:RMPS1=P*<HDMI1 | | RMPS1=P*<HDMI1 | ✓ | |
| | | HDMI2 | VXX:RMPS1=P*<HDMI2 | | RMPS1=P*<HDMI2 | ✓ | |
| | | HDMI3 | VXX:RMPS1=P*<HDMI3 | | RMPS1=P*<HDMI3 | ✓ | |
| | | DIGITAL LINK | VXX:RMPS1=P*<DLINK | | RMPS1=P*<DLINK | ✓ | |
| REMOTE2 - PIN8 | NONE | | VXX:RMPS1=P8<NONE | QVX:RMPS1=P8 | RMPS1=P8<NONE | ✓ | |
| | SHUTTER | SHUTTER | VXX:RMPS1=P8<SHUTTER | | RMPS1=P8<SHUTTER | ✓ | |
| FUNCTION BUTTON | DISABLE | | OFC:0 | QFC | 0 | ✓ | |
| | SYSTEM SELECTOR | | OFC:1 | | 1 | ✓ | |
| | SYSTEM DAYLIGHT VIEW | | OFC:2 | | 2 | ✓ | |
| | SUB MEMORY | | OFC:3 | | 3 | ✓ | |
| | ANGLE MONITOR | | OFC:15 | | 15 | ✓ | |
| DATE AND TIME-DATE SETTING | Year: yyyy | | TSD:201506151 | QGD | 201506161 | ✓ | |
| | Month: mm | | TSD:yyyymmddw | | yyyymmddw | ✓ | |
| | Date: dd | | | | | ✓ | |
| | Day:w(1~7:Mon~Sun) | | | | | ✓ | |
| DATE AND TIME-TIME SETTING | Hour: hh | | TST:154503 | QGT | 154503 | ✓ | |
| | Minute: mm | | TST:hmmss | | hmmss | ✓ | |
| | Second: ss | | | | | ✓ | |
| DATE AND TIME-NTP SYNCHRONIZATION | OFF | | VXX:NTPI0=+00000 | QVX:NTPI0 | NTPI0=+00000 | ✓ | |
| | ON | | VXX:NTPI0=+00001 | | NTPI0=+00001 | ✓ | |
| LENS TYPE | ET-ELS20 | | VXX:LNSI6=+00000 | QVX:LNSI6 | LNSI6=+00000 | ✓ | |
| | ET-ELW21 | | VXX:LNSI6=+00001 | | LNSI6=+00001 | ✓ | |
| | ET-ELW22 | | VXX:LNSI6=+00002 | | LNSI6=+00002 | ✓ | |
| | ET-ELW20 | | VXX:LNSI6=+00003 | | LNSI6=+00003 | ✓ | |
| | ET-ELT22 | | VXX:LNSI6=+00004 | | LNSI6=+00004 | ✓ | |
| | ET-ELT23 | | VXX:LNSI6=+00005 | | LNSI6=+00005 | ✓ | |
| | ET-ELU20 | | VXX:LNSI6=+00006 | | LNSI6=+00006 | ✓ | |
| LENS CALIBRATION | EXECUTE (ALL) | | VXX:LNSI0=+00001 | | | ✓ | |
| INITIALIZE-ALL USER DATA | USER INITILIZE | | VXX:RSTS1=0password | | | ✓ | |
| | USER RESTORE | | VXX:RSTS1=1password | | | ✓ | |
| INITIAL START UP | STANDBY | | OPY:0 | QPY | 0 | ✓ | |
| | ON | | OPY:1 | | 1 | ✓ | |
| | LAST MEMORY | | OPY:2 | | 2 | ✓ | |
| EMULATE | DEFAULT | | VXX:EMUI0=+00001 | QVX:EMUI0 | EMUI0=+00001 | ✓ | |
| | D3500 | | VXX:EMUI0=+00002 | | EMUI0=+00002 | ✓ | |
| | D4000 | | VXX:EMUI0=+00003 | | EMUI0=+00003 | ✓ | |
| | D/W5k SERIES | | VXX:EMUI0=+00004 | | EMUI0=+00004 | ✓ | |
| | D/W/Z6k SERIES | | VXX:EMUI0=+00005 | | EMUI0=+00005 | ✓ | |
| | L730 | | VXX:EMUI0=+00006 | | EMUI0=+00006 | ✓ | |
| | L780 | | VXX:EMUI0=+00007 | | EMUI0=+00007 | ✓ | |
| | L735 | | VXX:EMUI0=+00008 | | EMUI0=+00008 | ✓ | |
| | L785 | | VXX:EMUI0=+00009 | | EMUI0=+00009 | ✓ | |
| | LB/W SERIES | | VXX:EMUI0=+00010 | | EMUI0=+00010 | ✓ | |
| | F/W SERIES | | VXX:EMUI0=+00011 | | EMUI0=+00011 | ✓ | |
| | LZ370 | | VXX:EMUI0=+00012 | | EMUI0=+00012 | ✓ | |
| | VX500 SERIES | | VXX:EMUI0=+00013 | | EMUI0=+00013 | ✓ | |
| | EZ570 SERIES | | VXX:EMUI0=+00014 | | EMUI0=+00014 | ✓ | |
| | VW431D SERIES | | VXX:EMUI0=+00015 | | EMUI0=+00015 | ✓ | |
| AUDIO SETTING-VOLUME | 0 | | AVL:000 | QAV | 000 | ✓ | |
| | 63 | | AVL:063 | | 063 | ✓ | |
| AUDIO SETTING-IN STANDBY MODE | OFF | | VXX:ASBI0=+00000 | QVX:ASBI0 | ASBI0=+00000 | ✓ | |
| | ON | | VXX:ASBI0=+00001 | | ASBI0=+00001 | ✓ | |
| AUDIO SETTING-IN SHUTTER MODE | OFF | | VXX:ASHI1=+00000 | QVX:ASHI1 | ASHI1=+00000 | ✓ | |
| | ON | | VXX:ASHI1=+00001 | | ASHI1=+00001 | ✓ | |
| AUDIO SETTING-AUDIO IN SELECT- | AUDIO IN 1 | | VXX:AINI0=+00000 | QVX:AINI0 | AINI0=+00000 | ✓ | |
| AUDIO SETTING-AUDIO IN SELECT-HDMI1 | HDMI1 AUDIO IN | | VXX:AINI3=+00003 | QVX:AINI3 | AINI3=+00003 | ✓ | |
| | AUDIO IN 1 | | VXX:AINI3=+00000 | | AINI3=+00000 | ✓ | |
| AUDIO SETTING-AUDIO IN SELECT-HDMI2 | HDMI2 AUDIO IN | | VXX:AINI7=+00003 | QVX:AINI7 | AINI7=+00003 | ✓ | |
| | AUDIO IN 1 | | VXX:AINI7=+00000 | | AINI7=+00000 | ✓ | |

| CATEGORY | FUNCTION | Parameter/Name | Sub-Parameter | CONTROL | | QUERY | | MZ882 SERIES | |
|--------------------------------------|--|--------------------------|--------------------|--------------------|-------------------|----------------------|---|--------------|---|
| | | | | COMMANDS/CALL BACK | COMMANDS | CALL BACK | | | |
| CONTROL | AUDIO SETTING-AUDIO IN SELECT-HDMI3 | HDMI3 AUDIO IN | | VXX:AINIC=+00003 | QVX:AINIC | AINIC=+00003 | | ✓ | |
| | | AUDIO IN 1 | | VXX:AINIC=+00000 | | AINIC=+00000 | | ✓ | |
| | AUDIO SETTING-AUDIO IN SELECT-DIGITAL LINK | DIGITAL LINK AUDIO IN | | VXX:AINI8=+00005 | QVX:AINI8 | AINI8=+00005 | | ✓ | |
| | | AUDIO IN 1 | | VXX:AINI8=+00000 | | AINI8=+00000 | | ✓ | |
| | FILTER COUNTER-TIMER | OFF | | VXX:FCTI1=+00000 | QVX:FCTI1 | FCTI1=+00000 | | ✓ | |
| | | 1000H | | VXX:FCTI1=+01000 | | FCTI1=+01000 | | ✓ | |
| | | 2000H | | VXX:FCTI1=+02000 | | FCTI1=+02000 | | ✓ | |
| | | 3000H | | VXX:FCTI1=+03000 | | FCTI1=+03000 | | ✓ | |
| | | 4000H | | VXX:FCTI1=+04000 | | FCTI1=+04000 | | ✓ | |
| | | 5000H | | VXX:FCTI1=+05000 | | FCTI1=+05000 | | ✓ | |
| | | 6000H | | VXX:FCTI1=+06000 | | FCTI1=+06000 | | ✓ | |
| | | 7000H | | VXX:FCTI1=+07000 | | FCTI1=+07000 | | ✓ | |
| | | 8000H | | VXX:FCTI1=+08000 | | FCTI1=+08000 | | ✓ | |
| | | 9000H | | VXX:FCTI1=+09000 | | FCTI1=+09000 | | ✓ | |
| | | 10000H | | VXX:FCTI1=+10000 | | FCTI1=+10000 | | ✓ | |
| | | 11000H | | VXX:FCTI1=+11000 | | FCTI1=+11000 | | ✓ | |
| | | 12000H | | VXX:FCTI1=+12000 | | FCTI1=+12000 | | ✓ | |
| | | 13000H | | VXX:FCTI1=+13000 | | FCTI1=+13000 | | ✓ | |
| | | 14000H | | VXX:FCTI1=+14000 | | FCTI1=+14000 | | ✓ | |
| | | 15000H | | VXX:FCTI1=+15000 | | FCTI1=+15000 | | ✓ | |
| | | 15000H | | VXX:FCTI1=+16000 | | FCTI1=+16000 | | ✓ | |
| | | 15000H | | VXX:FCTI1=+17000 | | FCTI1=+17000 | | ✓ | |
| | | 15000H | | VXX:FCTI1=+18000 | | FCTI1=+18000 | | ✓ | |
| | | 15000H | | VXX:FCTI1=+19000 | | FCTI1=+19000 | | ✓ | |
| | | 16000H | | VXX:FCTI1=+20000 | | FCTI1=+20000 | | ✓ | |
| | FILTER COUNTER-RESET | | | VXX:FCTI2=+00000 | | | | | ✓ |
| | MODEL NAME | | MODEL NAME | | QID | MODEL NAME | | | ✓ |
| | SERIAL NUMBER | | SW0101234 | | QSN | SW0101234 | | | ✓ |
| | PROJECTOR RUNTIME | | 7864320H | | QVX:RTMS1 | RTMS1=7864320 | | | ✓ |
| | LAMP1(LIGHT1) RUNTIME | | 9999H | | Q\$L:1 | 9999 | | | ✓ |
| | LIGHT1 RUNTIME | | 7864320H | | QVX:LRTS3=00 | LRTS3=00:7864320 | | | ✓ |
| | LIGHT STATUS | | ALL OFF | | QLS | 0 | | | ✓ |
| | | | 1:ON, 2:OFF | | | 1 | | | ✓ |
| | LAMP(LIGHT) CONTROL STATUS | | LAMP OFF | | Q\$\$ | 0 | | | ✓ |
| | | | In turning ON | | | 1 | | | ✓ |
| | | | LAMP ON | | | 2 | | | ✓ |
| | | | LAMP Cooling | | | 3 | | | ✓ |
| | AIR FILTER MODEL NUMBER | | FILTER MODELNAME | | QVX:FMNS0 | FMNS0=FIL TERMODELNO | | | ✓ |
| | AIR FILTER TYPE | | NORMAL | MFS:3 | QFI:2 | 0 | | | ✓ |
| | | | SPECIAL | MFS:4 | | 1 | | | ✓ |
| | FILTER COUNTER | | 99999H | | QFI:0 | 99999 | | | ✓ |
| | MAC ADDRESS | | AB0102030405 | | QMA | AB0102030405 | | | ✓ |
| | MAIN FIRMWARE VERSION | | V1.00.01 | | QVX:SVRS0 | SVRS0=1.00.01 | | | ✓ |
| | SUB FIRMWARE VERSION | | V1.00.01 | | QVX:SVRS2 | SVRS2=1.00.01 | | | ✓ |
| | INPUT SIGNAL NAME | | CHANNEL1 (MAIN CH) | | QVX:NSGS1 | NSGS1=*****..... | | | ✓ |
| | DC OUT | | OFF | VXX:DCOI1=+00000 | QVX:DCOI1 | DCOI1=+00000 | | | ✓ |
| | | | ON | VXX:DCOI1=+00001 | | DCOI1=+00001 | | | ✓ |
| | TEMPERATURE (INTAKE) | | 0030/0080 | | QTM:0 | 0030/0080 | | | ✓ |
| | TEMPERATURE (EXHAUST AIR) | | 0030/0080 | | QTM:1 | 0030/0080 | | | ✓ |
| | TEMPERATURE (OPTICS MODULE) | | 0030/0080 | | QTM:2 | 0030/0080 | | | ✓ |
| | TEMPERATURE (LIGHT1 / LIGHT1-B) | | 0030/0080 | | QTM:11 | 0030/0080 | | | ✓ |
| | LAN data Cloning Write protect | | OFF | LCL:WRP0 | QCL:WRP | QCL:WRP0 | | | ✓ |
| | | | ON | LCL:WRP1 | | QCL:WRP1 | | | ✓ |
| | HDMI-CEC | | OFF | SHC:FNC0 | QHC:FNC | QHC:FNC0 | | | ✓ |
| | | | ON | SHC:FNC1 | | QHC:FNC1 | | | ✓ |
| HDMI-CEC HDMI1 (Change Device) | | NEXT | SHC:HM1NXT | | | | | ✓ | |
| | | PREVIEW | SHC:HM1PRE | | | | | ✓ | |
| HDMI-CEC HDMI1 (Get Device Name) | | DEVICE NAME | | QHC:HM1 | QHC:HM1DEVICENAME | | | ✓ | |
| HDMI-CEC HDMI2 (Change Device) | | NEXT | SHC:HM2NXT | | | | | ✓ | |
| | | PREVIEW | SHC:HM2PRE | | | | | ✓ | |
| HDMI-CEC HDMI2 (Get Device Name) | | DEVICE NAME | | QHC:HM2 | QHC:HM2DEVICENAME | | | ✓ | |
| HDMI-CEC HDMI3 (Change Device) | | NEXT | SHC:HM3NXT | | | | | ✓ | |
| | | PREVIEW | SHC:HM3PRE | | | | | ✓ | |
| HDMI-CEC HDMI3 (Get Device Name) | | DEVICE NAME | | QHC:HM3 | QHC:HM3DEVICENAME | | | ✓ | |
| HDMI-CEC - MENU CODE | | 0x09 (ROOT) | SHC:MNC1 | QHC:MNC | QHC:MNC1 | | | ✓ | |
| | | 0x0A (SETUP) | SHC:MNC2 | | QHC:MNC2 | | | ✓ | |
| | | 0x0B (CONTENTS) | SHC:MNC3 | | QHC:MNC3 | | | ✓ | |
| | | 0x0C (FAVORITE) | SHC:MNC4 | | QHC:MNC4 | | | ✓ | |
| | | 0x10 (MEDIA TOP) | SHC:MNC5 | | QHC:MNC5 | | | ✓ | |
| | | 0x11 (MEDIA POP UP) | SHC:MNC6 | | QHC:MNC6 | | | ✓ | |
| HDMI-CEC - PROJECTOR -> DEVICE | | DISABLE | SHC:PTSOFF | QHC:PTS | QHC:PTSOFF | | | ✓ | |
| | | POWER OFF | SHC:PTSPOF | | QHC:PTSPOF | | | ✓ | |
| | | POWER ON/OFF | SHC:PTSPWR | | QHC:PTSPWR | | | ✓ | |
| HDMI-CEC - DEVICE -> PROJECTOR | | DISABLE | SHC:STPOFF | QHC:STP | QHC:STPOFF | | | ✓ | |
| | | POWER ON | SHC:STPPON | | QHC:STPPON | | | ✓ | |
| | | POWER ON/OFF | SHC:STPPWR | | QHC:STPPWR | | | ✓ | |
| TEST PATTERN | TEST PATTERN | Off | OTS:00 | QTS | 00 | | | ✓ | |
| | | White | OTS:01 | | 01 | | | ✓ | |
| | | Black | OTS:02 | | 02 | | | ✓ | |
| | | Window | OTS:05 | | 05 | | | ✓ | |
| | | Reversed Window | OTS:06 | | 06 | | | ✓ | |
| | | Cross Hatch | OTS:07 | | 07 | | | ✓ | |
| | | Color Bar V | OTS:08 | | 08 | | | ✓ | |
| | | Convergence | OTS:11 | | 11 | | | ✓ | |
| | | Color Bar Side | OTS:51 | | 51 | | | ✓ | |
| | | 16:9/4:3 | OTS:59 | | 59 | | | ✓ | |
| | | Gradation 3 | OTS:62 | | 62 | | | ✓ | |
| | | Gradation 4 | OTS:63 | | 63 | | | ✓ | |
| | | | | OEM | | | | | ✓ |
| | SIGNAL LIST | SIGNAL LIST-REGISTRATION | | | | | | | ✓ |
| | | SIGNAL LIST-DELETE | A1 | | ODM:A1 | | | | ✓ |
| | | A2 | | ODM:A2 | | | | ✓ | |
| | | A7 | | ODM:A7 | | | | ✓ | |
| | | A8 | | ODM:A8 | | | | ✓ | |
| | | L1 | | ODM:L1 | | | | ✓ | |
| | | L2 | | ODM:L2 | | | | ✓ | |
| | | L7 | | ODM:L7 | | | | ✓ | |
| | | L8 | | ODM:L8 | | | | ✓ | |
| SUB MEMORY LIST-CHANGEVER | | 01 | | OCS:01 | | | | ✓ | |
| | | 96 | | OCS:96 | | | | ✓ | |
| SUB MEMORY LIST-CHANGEVER (EXTENDED) | | 01 | | OCS:01-01 | | | | ✓ | |
| | | 96 | | OCS:95-96 | | | | ✓ | |
| SUB MEMORY LIST-REGISTRATION | | | | OES | | | | ✓ | |
| SUB MEMORY LIST-DELETE | | 01 | | ODS:01-01 | | | | ✓ | |
| | 96 | | ODS:95-96 | | | | ✓ | | |
| SUB MEMORY USAGE STATE | 01 | | | QSB | 01 | | ✓ | | |
| | 96 | | | | 96 | | ✓ | | |
| SECURITY | SECURITY SETTING | OFF | | QVX:SPWI1 | SPWI1=+00000 | | | ✓ | |
| | | ON | | | SPWI1=+00001 | | | ✓ | |
| | CONTROL DEVICE SETUP-CONTROL PANEL | DISABLE | | VXX:CDSI1=+00000 | QVX:CDSI1 | CDSI1=+00000 | | ✓ | |
| | | ENABLE | | VXX:CDSI1=+00001 | | CDSI1=+00001 | | ✓ | |
| | | USER | | VXX:CDSI1=+00002 | | CDSI1=+00002 | | ✓ | |
| CONTROL DEVICE SETUP-REMOTE CONTROL | DISABLE | | VXX:CDSI2=+00000 | QVX:CDSI2 | CDSI2=+00000 | | ✓ | | |
| | ENABLE | | VXX:CDSI2=+00001 | | CDSI2=+00001 | | ✓ | | |
| | USER | | VXX:CDSI2=+00002 | | CDSI2=+00002 | | ✓ | | |

| CATEGORY | FUNCTION | Parameter/Name | Sub-Parameter | CONTROL | QUERY | | MZ882 SERIES MZ882 MZ782 MZ682 SMZ85C SMZ75C SMZ60C SMZ58CA |
|-------------------------------|--|------------------------|------------------|----------------------|--------------|-------------------------|--|
| | | | | COMMANDS/CALL BACK | COMMANDS | CALL BACK | |
| NETWORK | DIGITAL LINK MODE | AUTO | | VXX:DKMI1=+00001 | QVX:DKMI1 | DKMI1=+00001 | ✓ |
| | | DIGITAL LINK | | VXX:DKMI1=+00002 | | DKMI1=+00002 | ✓ |
| | | ETHERNET | | VXX:DKMI1=+00003 | | DKMI1=+00003 | ✓ |
| | | LONG REACH MODE | | VXX:DKMI1=+00004 | | DKMI1=+00004 | ✓ |
| | DIGITAL LINK-DUPLEX(Ethernet) | Auto negotiation | | VXX:DKDI1=+00000 | QVX:DKDI1 | DKDI1=+00000 | ✓ |
| | | 100BaseTX-Full | | VXX:DKDI1=+00001 | | DKDI1=+00001 | ✓ |
| | | 100BaseTX-Half | | VXX:DKDI1=+00002 | | DKDI1=+00002 | ✓ |
| | DIGITAL LINK-DUPLEX(DIGITAL LINK) | Auto negotiation | | VXX:DKDI2=+00000 | QVX:DKDI2 | DKDI2=+00000 | ✓ |
| | | 100BaseTX-Full | | VXX:DKDI2=+00001 | | DKDI2=+00001 | ✓ |
| | | 100BaseTX-Half | | VXX:DKDI2=+00002 | | DKDI2=+00002 | ✓ |
| | DIGITAL LINK STATUS-LINK | NO LINK | | | QVX:DKSI1 | DKSI1=+00000 | ✓ |
| | | DIGITAL LINK | | | | DKSI1=+00001 | ✓ |
| | | LPM | | | | DKSI1=+00002 | ✓ |
| | | ETHERNET | | | | DKSI1=+00003 | ✓ |
| | DIGITAL LINK STATUS-HDCP STATUS | NO SIGNAL | | | QVX:DKSI2 | DKSI2=+00000 | ✓ |
| | | OFF | | | | DKSI2=+00001 | ✓ |
| | | ON | | | | DKSI2=+00002 | ✓ |
| | DIGITAL LINK STATUS-SIGNAL QUALITY (MIN) | -255 | | | QVX:DKSI3 | DKSI3=-00255 | ✓ |
| | | 0 | | | | DKSI3=+00000 | ✓ |
| | DIGITAL LINK STATUS-SIGNAL QUALITY (MAX) | -255 | | | QVX:DKSI4 | DKSI4=-00255 | ✓ |
| | | 0 | | | | DKSI4=+00000 | ✓ |
| | DIGITAL LINK INPUT CH LIST | H01:HDMI1,H02:HDMI2... | | | QVX:DL1S1 | DL1S1=H01:HDMI1,***:*** | ✓ |
| | PROJECTOR NAME SETTING | PROJECTOR1 | | VXX:NCGS8=PROJECTOR1 | QVX:NCGS8 | NCGS8=PROJECTOR1 | ✓ |
| | Art-Net SETUP | OFF | | VXX:DANI1=+00000 | QVX:DANI1 | DANI1=+00000 | ✓ |
| ON(2.*.*) | | | VXX:DANI1=+00002 | | DANI1=+00002 | ✓ | |
| ON(10.*.*) | | | VXX:DANI1=+00003 | | DANI1=+00003 | ✓ | |
| ON(MANUAL) | | | VXX:DANI1=+00004 | | DANI1=+00004 | ✓ | |
| Art-Net SETUP-START ADDRESS | 1 | | VXX:DANI3=+00001 | QVX:DANI3 | DANI3=+00001 | ✓ | |
| | 501 | | VXX:DANI3=+00501 | | DANI3=+00501 | ✓ | |
| Art-Net SETUP-NET | 0 | | VXX:DANI4=+00000 | QVX:DANI4 | DANI4=+00000 | ✓ | |
| | 127 | | VXX:DANI4=+00127 | | DANI4=+00127 | ✓ | |
| Art-Net SETUP-SUB NET | 0 | | VXX:DANI5=+00000 | QVX:DANI5 | DANI5=+00000 | ✓ | |
| | 15 | | VXX:DANI5=+00015 | | DANI5=+00015 | ✓ | |
| Art-Net SETUP-UNIVERS | 0 | | VXX:DANI6=+00000 | QVX:DANI6 | DANI6=+00000 | ✓ | |
| | 15 | | VXX:DANI6=+00015 | | DANI6=+00015 | ✓ | |
| Art-Net SETUP-CHANNEL SETTING | DEFAULT | | VXX:DANI8=+00000 | QVX:DANI8 | DANI8=+00000 | ✓ | |
| | 1 | | VXX:DANI8=+00001 | | DANI8=+00001 | ✓ | |
| | 2 | | VXX:DANI8=+00002 | | DANI8=+00002 | ✓ | |
| | USER | | VXX:DANI8=+00100 | | DANI8=+00100 | ✓ | |
| | | | | | | | ✓ |

Note: The commands or parameters with "*" shows available commands or parameters for the projector which has been activated by the Upgrade Kit.